

Vision Sensor

FH Series

Vision System



FH-505□

FH-SMDA-GS050B

NOTE -

- · All rights reserved.
- · No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- · No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions.

Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- This software is based in part on the work of the Independent JPEG Group.
- · Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Intel, Core and Pentium are trademarks of Intel Corporation in the U.S. and/or other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD, SDHC, microSD, and microSDHC logos are trademarks of SD-3C, LLC.









- QR Code is a registered trademark of DENSO WAVE INCORPORATED.
- MELSEC is a registered trademarks of Mitsubishi Electric Corporation.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots reprinted with permission from Microsoft.

CONTENTS

Int	troduc	ction	4			
Te	Terms and Conditions Agreement5					
Sa	fety F	Precautions	7			
]				
Pr	ecaut	ions for Safe Use	14			
Pr	ecaut	ions for Correct Use	20			
		ions and Standards				
		Manuals				
		n History				
1.		erview				
	1.1.	Overview	31			
	1.2.	Target Audience				
	1.3.	Work Flow				
2.	Svs	tem Configuration				
	2.1.	System Configuration				
	2.2.	Applicable Devices				
3.		figuration of the Application				
	3.1.	Specification of the Sensor				
	3.2.	Workpiece				
	3.3.	Container				
	3.4.	Supported Robots				
4.		ipment Installation Ovewrview				
	-9 0 4.1.	Mounting				
	4.2.	Wiring				
	4.3.	Connecting				
	4.4.	Camera Cable Mounting				
	4.5.	Start and Stop Sequence				
5.	_	rtup Procedure				
	5.1.	Preconditions				
	5.2.	What You Can Do by This Startup Procedure				
6.	_	ating Data Set for the Robot Vision				
	6.1.	Creating Data Sets				
7.	_	Sensor Software Installation				
	7.1.	Installing and Uninstalling the 3D Robot Vision Softwa				
		47	0			
	7.2.	Loading the Sensor Controller Project	60			
	7.3.	Configuring the Network (Ethernet Communications) .				
8.	-	on Sensor Setting for Robot Vision				
	8.1.	Overview				
	8.2.	Coordinate Systems and Angle Types				
	8.3.	Scene Data Configuration				
	8.4.	User Dialogs				
	8.5.	Hand-eye Calibration Configuration Using the Wizard				
	8.6.	Hand-eye Camera Pick Application Configuration Usin				
		izard	_			
	8.7.	Hand-eye Calibration				
	8.8.	Pick Application Flow for the Hand-Eye Camera Syste				
	J.J.	117	,,,,,			
9.	Δnr	pendix1	73			
_	אר. 9.1.	Making Hand (Tow finger Gripper) and Grasp Point				
	-	tration1	173			
	_		197			

Introduction

Thank you for purchasing the FH Series.

This manual contains information that is necessary to use the FH Series.

Please read this manual and make sure you understand the functionality and performance of the FH Series before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Terms and Conditions Agreement

Warranty, Limitations of Liability Warranties

Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANYWAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

Symbols and the Meanings for Safety Precautions Described in This Manual

The following notation is used in this manual to provide precautions required to ensure safe usage of a Sensor Controller. The safety precautions that are provided are extremely important to safety.

Always read and heed the information provided in all safety precautions. The following notation is used.

<u></u> WARNING	Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.
<u> Caution</u>	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

Meanings of Alert Symbols

General Prohibition Indicates general prohibitions, including warnings, for which there is no specific symbol
General Caution Indicates general cautions, including warnings, for which there is no specific symbol.
The filled circle symbol indicates operations that you must do. The specific operation is shown in the circle and explained in text. This example shows a general precaution for something that you must do.
Electrical Hazard Indicates the possible danger of electric shock under specific conditions.
Explosion Hazard Indicates the possible danger of explosion under specific conditions.
LED light Hazard Indicates the possible danger of LED radiation or light.
High Temperature Caution Indicates the possible danger of injury by high temperature under specific conditions.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

⚠ WARNING

This product must be used according to this manual and Instruction Sheet. Failure to observe this may result in the impairment of functions and performance of the product.



This product is not designed or rated for ensuring the safety of persons. Do not use it for such purposes.



Never connect the AC power supply with this product. When the AC power supply is connected, it causes the electric shock and a fire.



A lithium battery is built into the Controller and may occasionally combust, explode, or burn if not treated properly. Dispose of the Controller as industrial waste, and never disassemble, apply pressure that would deform, heat to 100°C or higher, or incinerate the Controller.



If you keep watching the LED light, it may have an adverse effect on the eyes, do not stare directly into the light emitted from the LED. If a specular object is used, take care not to allow reflected light to enter your eyes.



Do not touch the terminals while the power supply is ON. Doing so may result in electrical shock.



Please take external safety measures so that the system as a whole should be on the safe side even if a failure of a Sensor Controller, a failure of a 3D Vision Sensor, or an error due to an external factor occurred. An abnormal operation may result in serious accident.




Please take fail-safe measures on your side in preparation for an abnormal signal due to signal conductor disconnection and/or momentary power interruption.



An abnormal operation may result in a serious accident.

FH series must be handled by those who have the expertise in electricity. Read the reference manuals carefully to understand the contents well, and make the proper use of this product accordingly. Keep this document safely for ready reference at any time.





According to Article 36, 31 and 32 of the Occupational Health and Safety Regulations, work to teach, inspect, repair and adjust industrial robots falls under "dangerous or harmful work" as defined in the Occupational Health and Safety Act. Under Article 59 of the Occupational Safety and Health Act, operators are obliged to provide workers with "special training for safety or health".



Check the measurement results before operating the robot. Otherwise the robot may act in an unintended manner. Change the workpiece position and angle of picking/placing and check the operation thoroughly.



The scene variables and system variables that are set in advance for the scene loaded with the environment copy function are automatically set using operations on the dialog box. Do not directly set them using the processing item setting screen or the TDM editor.



FH series does not comply with the laws and regulations for industrial robot safety. When using the FH series in a robot system that includes an industrial robot, be sure to check for compliance with laws and regulations regarding the safety of industrial robots. Take steps to ensure safety as needed.



It is your responsibility to implement appropriate safety measures based on the results of risk assessment. Compliance with the Robot Safety Guide and all of the information contained in our Robotic System Product Information does not guarantee that personal injury or damage to equipment caused by an industrial robot will be avoided.



During maintenance, disconnect the robot's AC power supply and lock out or tag out the power supply to prevent powering up. If the following safety measures are not taken, the subject robot may cause death or serious injury or damage to the robot itself or its peripheral equipment.



- Workers who install, operate, teach, program, or maintain the system should read the "Robot Connection Guide (Cat. No. Z448, Z447)" and "Robot Safety Guide (Cat. No. I590)" and take a training course on their responsibilities with the robot.
- Those who design a robot system must read this document and the Robot Safety Guide, and follow the safety regulations and laws in the area where the robot will be installed.
- Do not use the subject robot for any purpose other than those described in this document and the manuals referred to in the Robot Connection Guide. If you are not sure whether your application is compatible, please contact us.
- The user is responsible for installing safety barriers around the robot to prevent workers from entering the work area and coming into contact with it while it is in operation.
- During maintenance, the power to the robot and the main power supply must be locked out and tagged out (measures and indication of prohibition from being turned on) to prevent them from being turned on.

If you proceed to the next step before registering the HandEye calibration start position, the robot may operate unintentionally. Be sure to register the start position.



The robot is driven by pressing the Jog Move button and the Robot Move button. The operation must be done by shoes who have completed special health and safety training. The system must be operated so that it can be stopped at any time by an emergency stop button.



Check the measurement results before operating the robot. Otherwise the robot may act in an unintended manner. Change the workpiece position and angle and check the operation thoroughly.



If the robot is operated with an incorrectly shaped hand, the robot may pick and hold the workpiece in an unintended position and/or posture, damaging the workpiece, container, or hand and causing it to fly out into the environment. Check the dimensions of the drawing and



the actual product, and make registration securely. Change the workpiece position and angle of picking/placing and check the operation thoroughly. The system must be operated so that it can be stopped at any time by an emergency stop button.

Registering the grasp point that interferes with the workpiece may damage the hand or the workpiece. Register the gripping position that does not interfere with the work.



If the robot is operated with an incorrectly selected picking and holding DB or hand data, the robot may pick and hold the workpiece in an unintended position and/or posture, damaging the workpiece, container, or hand and causing it to fly out into the environment. Select the proper picking and holding DB in the picking and holding plan setting. Make sure to perform offline measurement before operating the robot to confirm that the proper hand is selected.



If the robot is operated with incorrect sensor controller project data, it may act in an unintended manner, resulting in contact with humans, scattering of workpieces, and contact with surrounding objects. Make sure that the proper environment file for the robot is loaded.



If the robot is operated after changing the floor or container height, it may collide with the floor. If the container position or floor level is changed, register the floor level and container again.



If the 3D Vision Sensor shape is not registered, the 3D Vision Sensor may collide with the container and be damaged. Please register the 3D Vision Sensor shape when you register the hand data.



Do not perform camera calibration during the warm-up operation of the 3D Vision Sensor.



Measurement errors occur when the geometric positional relationship between the lighting section and imaging section of the 3D Vision Sensor changes due to factors such as aging, temperature changes, or impact on the 3D Vision Sensor. Perform a camera calibration check on a regular basis and calibrate the camera if necessary.



Do not perform hand-eye calibration during the warm-up operation of the 3D Vision Sensor.



Complete sensor calibration before performing hand-eye calibration.



Anti-virus protection

Install the latest commercial-quality antivirus software on the computer connected to the control system and maintain to keep the software up-to-date.



Security measures to prevent unauthorized access

Take the following measures to prevent unauthorized access to our products.

• Install physical controls so that only authorized personnel can access control systems and equipment.



- Reduce connections to control systems and equipment via networks to prevent access from untrusted devices.
- Set strong passwords and change them frequently.

• Scan virus to ensure safety of USB drives or other external storages before connecting them to control systems and equipment.

Data input and output protection

Validate backups and ranges to cope with unintentional modification of input/output data to control systems and equipment.



- Checking the scope of data
- Checking validity of backups and preparing data for restore in case of falsification and abnormalities
- Safety design, such as emergency shutdown and fail-soft operation in case of data tampering and abnormalities



Data recovery

Backup data and keep the data up-to-date periodically to prepare for data loss.



When using an intranet environment through a global address, connecting to an unauthorized terminal such as a SCADA, HMI or to an unauthorized server may result in network security issues such as spoofing and tampering. You must take sufficient measures such as restricting access to the terminal, using a terminal equipped with a secure function, and locking the installation area by yourself.



When constructing an intranet, communication failure may occur due to cable disconnection or the influence of unauthorized network equipment. Take adequate measures, such as restricting physical access to network devices, by means such as locking the installation area.



When using a device equipped with the USB flash drive or SD Memory Card function, there is a security risk that a third party may acquire, alter, or replace the files and data in the removable media by removing the removable media or unmounting the removable media.



Please take sufficient measures, such as restricting physical access to the Controller or taking appropriate management measures for removable media, by means of locking the installation area, entrance management, etc., by yourself.

⚠ Caution

Danger of burns. Do not touch the case while the power is ON or just after power is turned OFF, since it remains extremely hot.



If the camera calibration is performed with the target tilted, the measurement error may deteriorate. Ensure that the calibration target is placed in a stable position on a flat floor.



If the camera calibration is performed while the target is dirty, the measurement error may deteriorate. If the camera calibration target is dirty, wring out a wet towel, wipe it clean, and dry it with a soft cloth before performing the calibration.



If the camera calibration is performed while the 3D Vision Sensor is dirty, the measurement error may deteriorate. If the 3D Vision Sensor window surface is dirty, wring out a wet towel, wipe the dirt off, and dry with a dry cloth.



When placing the camera calibration target, place it slowly so that your hands do not get caught on the floor.



Precautions for Safe Use

Be sure to respect following items for safety.

Condition of the Fitness of OMRON Products

- Omron products are designed and manufactured as general-purpose products for use in general industrial applications. They are not intended to be used in the following critical applications. If you are using Omron products in the following applications, Omron shall not provide any warranty for such Omron products, unless otherwise specifically agreed or unless the specific applications are intended by Omron.

 a) Applications with stringent safety requirements, including but not limited to nuclear power control equipment, combustion equipment, aerospace equipment, railway equipment, elevator/lift equipment, amusement park equipment, medical equipment, safety devices and other applications that could cause danger/harm to people's body and life.
- b) Applications that require high reliability, including but not limited to supply systems for gas, water and electricity, etc., 24 hour continuous operating systems, financial settlement systems and other applications that handle rights and property.
- c) Applications under severe condition or in severe environment, including but not limited to outdoor equipment, equipment exposed to chemical contamination, equipment exposed to electromagnetic interference and equipment exposed to vibration and shocks.
- d) Applications under conditions and environment not described in specifications.
- 1. In addition to the applications listed from (a) to (d) above, Omron products (see definition) are not intended for use in vehicles designed human transport (including two wheel vehicles). Please do NOT use Omron products for vehicles designed human transport. Please contact the Omron sales staff for information on our automotive line of products.
- 2. The above is part of the Terms and Conditions Agreement. Please use carefully read the contents of the guarantee and disclaimers described in our latest version of the catalog, data sheets and manuals.

Installation Environment (FH-505)

- Do not use the product in the environment with flammable or explosive gases.
- Regularly clean the vent holes or fan outlet to prevent dust or particles blocking them. Internal temperature increases when those are blocked, it causes malfunction.
- To secure safety for operation and maintenance, install the product apart from high-voltage devices and power devices.
- Make sure to tighten all screws in mounting.
- When mounting the product, be sure to tighten all screws.

Power Supply and Wiring (FH-505□)

- Make sure to use the product within the power voltage specified by catalog, manual, or instruction sheet.
- Never connect the product to AC power. If connected, it causes malfunction.
- The recommended power supply is the S8VS- $\square\square$ 24 (manufactured by OMRON) or S8VK-G- $\square\square$ 24 (manufactured by OMRON).
- Select and use the appropriate wire size based on consumption current.

- Keep the power supply wires as short as possible.
- Provide the power from a DC power supply (safety extra-low voltage circuits) that has been taken measures not to generate high-voltage.
- Check the following again before turning on the power.
- Are the voltage and polarity of the power supply correct? (24 VDC)
- Is the functional grounding terminal connected to the ground (FG)?
- Is not the load of the output signal short-circuited?
- Is the load current of the output signal appropriate?
- Is not the mistake found in wiring?

Grounding (FH-505□)

- Since the power supply circuit for the Sensor Controller is described in the manual and instruction sheet, please check it.
- When a base is packed in a camera that will be connected to the Sensor Controller, make sure to mount the camera using the base. Since the enclosure of the camera body is connected to the internal circuits, the circuits may cause short-circuit with FG if the base is not used to mount the camera and result in malfunction or damage.
- Apply Class D grounding (grounding resistance: 100 $[\Omega]$ or less) Wire the grounding wire for the Sensor Controller independently. If the grounding wire is shared with other devices or connected to a building beam, the Sensor Controller may be adversely affected.
- Check the wiring again before turning on the power.
- Do not ground the plus (+) terminal when the Sensor Controller is connected to the FH-SC12/FH- SM12. The internal circuits may cause a short-circuit and result in malfunction.
- When using the Sensor Controller and the peripheral devices such as a monitor, USB connection devices, RS-232C connection devices, there should be no potential difference in ground level. If not, it may cause malfunction.

Take measures that the potential difference does not occur between the grounds for the Sensor Controller and the peripheral devices.

Communications with Upper Device (FH-5050)

• After confirming that the product is started up, communicate with the high-order device. Since uncertain signals may be output from the high-order interface at the product start-up, take measures such as clearing the reception buffer of your device at the initial stage.

Failsafe Measures (FH-5050)

- Be sure to take fail-safe measures externally when controlling stages and robots by using the measurement results of the Sensor Controller (axis movement output by calibration and alignment measurement).
- On a Sensor Controller side, supplementary use operations and branches of the Sensor Controller to configure a check flow such as "data should not be externally provide if the data is in a range from -XXXXX to XXXXX" based on the stage/robots range of movement.

Others (FH-505)

- Use only the camera and cables designed specifically for the product. Use of other products may result in malfunction or damage of the product.
- Using an USB extension cable may cause malfunction or damage. Do not use commercially available extension cables.
- Please insert monitor connector perpendicularly so that the connector resin part and pin are not rubbing against each other. Damaged pin may cause contact failure due to generation and invasion of resin powder.
- Always turn OFF the power of the Sensor Controller and peripheral devices before connecting or disconnecting a camera or cable. Connecting the cable with power supplied may result in damage of the camera or peripheral devices.
- For the cable that is flexed repeatedly, use the robotic cable type (Bend resistant camera cable) to prevent damages.
- Do not apply torsion stress to the cable. It may damage the cable.
- Secure the minimum bending radius of the cable. Otherwise the cable may be damaged.
- Do not apply stress to the connector by pulling or bending the cable. It may damage the connector.
- Do not attempt to dismantle, repair, or modify the product.
- Should you notice any abnormalities, immediately stop use, turn OFF the power supply, and contact your OMRON representative.
- While the power is ON or immediately after the power is turned OFF, the Sensor Controller and camera case are still hot. Do not touch the case.
- When disposing of the product, treat it as an industrial waste.
- Do not drop the product nor apply excessive vibration or shock to the product. Doing so may cause malfunction or burning.
- This product is heavy. Be careful not to drop it while handling.
- Do not insert an SD memory card in the reverse orientation, at an angle, or in a twisting manner.
- Illumination is normal immediately after the power supply is turned ON. Do not look directly into the illumination light.
- A lithium battery is incorporated, so a severe injury may rarely occur due to ignition or explosion.

Installation Environment (FH-SMDA-GS050B)

- Do not use the product in the environment with flammable or explosive gases.
- To secure safety for operation and maintenance, install the product apart from high-voltage devices and power devices.
- Avoid installing the product in places with vibration as much as possible.

Power Supply and Wiring (FH-SMDA-GS050B)

- Make sure to use the product with the power supply voltage specified. If a DC voltage exceeding the rating or an AC voltage is applied, the circuit parts may be burnt or exploded.
- Do not connect the power supply with polarity reversed.
- Use a DC power supply with safety measures against high-voltage spikes (safety extra low-voltage circuits on the secondary side).

- Use an independent power source for this product. Do not use a shared power source.
- Never apply more than the rated voltage or AC power supply to this product. It may cause malfunction.
- The recommended power supplies are as follows:
 - When not attaching the lighting module, use S8VK-G06024 (OMRON) or S8VS-06024 (OMRON).
- Wire high-voltage cables or power cables are separated from the cables of this product. If the same cable or duct is used, the product may receive induction and it may cause malfunctioning or breakage.
- Do not short-circuit the load on the open collector output.
- Apply load not exceeding the rating.
- Before wiring an I/O cable, attach a crimping terminal. Do not connect cables just twisted together to the power supply or terminal block directly.
- Insulate unnecessary signal cables so that they do not contact any other signal cables.
- After wiring the cables, confirm if the power supply is appropriate, if there is miswiring such as short-circuit of load, if the load current is appropriate, and if FG is connected appropriately. Otherwise, the product may be broken due to miswiring etc.
- Take enough safety measures such as a failsafe circuit before using the product.
- Be sure to apply Class D grounding (100 Ω or lower grounding resistance) to the ground wire of the I/O cable.
- Do not share the ground wire with some other devices or connect it to the beam of the building. The product may be adversely affected.
- Determine the contact point as near as possible to shorten the ground wire as much as possible. The product may be adversely affected.
- For positive ground, please refer to cautions described in the setup manual.
- Do not touch the optical surface of the camera or the lighting section during wiring or installation. It may affect the characteristics.

Mounting (FH-SMDA-GS050B)

- When doing the following, be sure to turn OFF the power of the 3D vision sensor or connected peripheral devices. Not doing so leads to a product failure.
- Cable connection and wiring
- Connector mounting/removal
- Tighten the mounting screws securely using the defined torque. (Screw: M4 x 4 ,Tightening torque: 1.2 N•m)
- Do not apply torsional stress to the cable. Doing so may cause cable breakage.
- Secure the minimum bending radius of the cable. If it cannot be secured, the cable may be broken.

Others (FH-SMDA-GS050B)

- Use only the dedicated cable (FHV-VNBX2 / FHV-VNLBX2 / FHV-VNBX / FHV-VNLBX and FHV-VSDX-BX / FHV-VSDX-LBX). Otherwise, the product may malfunction or be broken.
- If anything abnormal occurs, for example, strange smell/sound is detected, the main unit gets very hot, or a smoke comes, stop using the product, turn OFF the product, and consult OMRON's branch or sales office.
- Do not disassemble, deform by pressurizing, incinerate, repair, or alter this product.

- When disposing of the product, treat as industrial waste.
- Do not use the product for atomic power or safety circuits endangering human lives.
- Do not drop the product or expose it to abnormal vibration or impact. Doing so may lead to product failure.
- When operating the robot by using the vision sensor measurement results, be sure to check the measurement result data on the robot side and take fail-safe measures, such as operating the robot only after confirming that the data is within the robot's range of motion.
- When operating the jog, check the actual robot visually instead of the camera image.
- The robot is driven when using the motion sample program. The operation must be done by shoes who have completed special health and safety training. The system must be operated so that it can be stopped at any time by an emergency stop button.
- If the operation range of hand-eye calibration is not set correctly, the robot may act in an unexpected position and/or posture that may result in contact with surrounding objects. Make sure that the calibration trajectory is clear and that there are no obstacles or people in the vicinity. The system must be operated so that it can be stopped at any time by an emergency stop button.
- 3D Vision Sensor measurements are relative, not absolute. It cannot be used as a measurement sensor.

Camera Calibration Target (FH-XCAL-S)

- Install and store the product in a location that meets the following conditions:
- Ambient temperature and relative humidity do not exceed the range of specifications
- No rapid changes in temperature (place where dew does not form)
- No presence of corrosive or flammable gases
- Place free of dust, salts and iron particles
- Place free of vibration and shock
- Place out of direct sunlight
- Place where it will not come into contact with oils or chemicals
- Do not drop the product nor apply excessive vibration or shock to the product. Doing so may cause malfunction or burning.
- Place the camera calibration target in a stable position on a flat floor.
- Set the camera calibration target within the measurement distance and measurement range of the 3D Vision Sensor to calibrate the camera.
- Before performing camera calibration automatically, make sure that the robot is in a coordinate position that does not collide with the target.

HandEye Calibration Target (FH-XCAL-R)

- Install and store the product in a location that meets the following conditions:
- No rapid changes in temperature (place where dew does not form)
- No presence of corrosive or flammable gases
- Place free of dust, salts and iron particles
- Place free of vibration and shock
- Place out of direct sunlight
- Place where it will not come into contact with oils or chemicals

- Do not drop the product nor apply excessive vibration or shock to the product. Doing so may cause malfunction or burning.
- Set the hand-eye calibration target within the measurement distance and measurement range of the 3D Vision Sensor to performing hand-eye calibration.
- When performing hand-eye calibration, make sure that there is no workpiece around the hand-eye calibration target.
- Install the hand-eye calibration target on a flat floor in a stable condition without vibration.
- If the hand-eye calibration target is dirty, wring out a wet towel, wipe off the dirt, and dry with a soft cloth.
- If the 3D Vision Sensor window surface is dirty, wring out a wet towel, wipe the dirt off, and dry with a dry cloth.
- Check that the hand-eye calibration result shows an error of approximately 1.0 or less.

Precautions for Correct Use

Please observe the following precautions to prevent failure to operate, malfunction, or undesirable effect.

Installation and Storage Sites (FH-505□)

Install and store the product in a location that meets the following conditions:

- Surrounding temperature of 0 to +45°C (-20 to +65°C in storage)
- No rapid changes in temperature (place where dew does not form)
- Relative humidity of between 35 to 85%
- No presence of corrosive or flammable gases
- Place free of dust, salts and iron particles
- Place free of vibration and shock
- Place out of direct sunlight
- Place where it will not come into contact with water, oils or chemicals
- Place not affected by strong electro-magnetic waves
- Place not near to high-voltage, or high-power equipment

Orientation of Product (FH-505)

• For efficient heat dissipation, install the product only with the orientation written in the manual or the Instruction Sheet. Install the product so that the air can flow freely through its cooling vents.

Ambient Temperature (FH-505□)

- To secure good ventilation, install the product with clearance written in the manual or the Instruction Sheet.
- Do not install the product immediately above significant heat sources, such as heaters, transformers, or large-capacity resistors.
- Use the product within the operating temperature range based on the specifications of it.
- Install a forced cooling fan or air conditioner not to exceed the operating temperature range when the ambient temperature is close to the upper limit of its range.

Noise Resistance (FH-505□)

- Do not install the Sensor Controller in a cabinet with high-voltage equipment installed.
- Mount the Sensor Controller at 200 [mm] or more from power cables apart.

Component Installation and Handling (FH-505□)

- When touching a terminal part or a signal wire in a connector, take anti-static measures using a wrist strap or another device to prevent damage from static electricity.
- Be sure to execute Device Information Storage Tool described in the Vision System FH/FHV Series User's Manual (Cat. No. Z365) when connecting USB memory device or SD memory card.
- When removing USB memory device or SD memory card, select Function menu System information Drive information on the main screen, then press the Eject button and confirm it is safe to remove.

• When using remote operation, before removing a USB memory device or SD memory card, make sure that data is not being read or written to them.

For a USB flash drive, the memory device's LED flashes or lights while data is being read or written, so make sure that it is turned OFF before removing the memory.

For SD memory card, the SD BUSY LED flashes or lights while data is being read or written, so make sure that it is turned OFF before removing the memory.

• Turning OFF the Power:

When a message is displayed indicating that a task is in progress, do not turn OFF the power. Doing so causes the data in the memory to be corrupted, resulting in the product not operating properly upon the next start-up.

Do not turn OFF during saving data to Sensor Controller.

When turns OFF, conform the followings proceedings have completed. and then operate again.

- When saves using Sensor Controller: Confirm the save processing is completed and next operation is possible.
- When saves using communication command: Intended command is completed. BUSY signal is turned OFF.
- After turning off the power, wait at least 1 second before restarting.

Maintenance (FH-505□)

- Turn OFF the power and ensure the safety before maintenance.
- Clean the lens with a lens-cleaning cloth or air brush.
- Lightly wipe off dirt with a soft cloth.
- Dirt on the image element must be removed using an air brush.
- Do not use thinners or benzine.

Connecting the Sensor Controller and Monitor with a Switcher and Splitter

• Do not use devices that may require re-recognition of the monitor by the Sensor Controller when a switching operation was performed. If such re-recognition processing happens at switching operation, it may cause measurement time to be longer.

Installation Location (FH-SMDA-GS050B)

In order to prevent the product from becoming inoperable or malfunction, and to prevent other adverse effects to the performance or equipment, please observe the following.

- A location where the ambient temperature does not exceed the rated range.
- A location where the temperature does not vary sharply (condensation occurs).
- A location where relative temperature does not exceed a range of 35-85%.
- A location not exposed to corrosive gases or combustible gases.
- A location not exposed to dust, salt, or metal powder.
- A location not exposed to direct vibration or impact.
- A location not exposed to strong disturbance light (laser light, arc welding light, or ultraviolet light).
- A location not near a heating appliance or exposed to direct sunlight.

- A location not exposed to mist of water, oil, or chemicals or misty atmosphere.
- A location not exposed to strong magnetic/electric fields.
- A location not near a high-voltage device or power device

Power Supply, Connection, and Wiring (FH-SMDA-GS050B)

- If using a commercially available switching regulator, earth the frame ground terminal.
- If the power supply line has surge, connect a surge absorber according to the operational environment to use the product.
- After wiring the cables, confirm if the power supply is appropriate, if there is miswiring such as short-circuit of load, or if the load current is appropriate. Otherwise, the product may be broken due to miswiring etc.
- Do not put load on the cables and connectors before wiring them.
- Turn on the power of the 3D Vision Sensor at the same time as or before turning on the power of the FH sensor controller.
- When turning OFF the power, confirm that data have been saved completely before starting operations.
- When data are saved by operating the 3D vision sensor, the saving process must have been completed and the following user operations must be possible.
- When data are saved using communication commands, processing of the applicable commands must have been completed and the busy state is OFF.
- Attach the cable straight with the terminal correctly aligned. Forcibly attaching the cable may bend the terminal, resulting in failure or communication error.
- Insulate the unused signal lines of the I/O cable so that the signal lines do not come into contact with other signal lines.

Maintenance (FH-SMDA-GS050B)

- Turn OFF the power and confirm safety before starting maintenance.
- Remove dirt on the window using the special cloth for lens or an air brush.
- Do not use thinner, alcohol, benzene, acetone, or kerosene to clean his product.

Optical axis (FH-SMDA-GS050B)

• Tthe field of view may vary product by product. When mounting this product, be sure to confirm video using the sensor controller.

Image Sensor (FH-SMDA-GS050B)

• For this product, a line may appear depending on the measurement condition or sensitivity because of the specification of the image sensor.

However, this is not a fault or failure of the product. In addition, although there may be multiple defective pixels, this is not a fault or failure of the product. Use the product as confirming the actual image.

Failsafe Measures (FH-SMDA-GS050B)

• When operating the robot by using the vision sensor measurement results, be sure to check the measurement result data on the robot side and take fail-safe measures, such as operating the robot only after confirming that the data is within the robot's range of motion.

Warm-up (FH-SMDA-GS050B)

• The correct brightness and focus may not be achieved or may fluctuate until the product function is stabilized (approximately 15 minutes) after power-on. Check the WARM UP indicator LED or the warm-up completion flag in the camera image input processing item on the FH software before using the product.

Camera Installation (FH-SMDA-GS050B)

• In an environment exposed to high humidity and sharp temperature fluctuation, the window may become cloudy in rare cases.

Connection and Operation with the Robot (FH-SMDA-GS050B)

- For an example design of a robot program to build an application, see the sample program (fhsample_main()) of the Robot Connection Guide.
- For the processing to move the robot to the imaging position, refer to the Robot Connection Guide.
- If you proceed to the next step before registering the workpiece reference position, the robot may operate unintentionally. Be sure to register the start position.
- If you proceed to the next step before registering the robot's picking and holding position, the robot may operate unintentionally. Be sure to register the start position.

LED Safety (FH-SMDA-GS050B)

This product is classified into the following risk groups by IEC62471.

LED safety	Display
	CAUTION
Risk group 2	Possibly hazardous optical radiation emitted from this product
	Risk Group 2 IEC 62471

Camera Calibration Target (FH-XCAL-S)

- Do not use thinner, alcohol, benzene, acetone, or kerosene to clean his product.
- Before calibrating the camera, make a backup of the AOS camera information file.
- After calibrating the camera, check the results to confirm that the calibration was successful. When an abnormal AOS camera information file is read, the measurement error increases and the wrong coordinate position is output.
- When disposing of this product, treat it as industrial waste and never heat or incinerate it at 100 °C or higher.

HandEye Calibration Target (FH-XCAL-R)

- Do not use thinner, alcohol, benzene, acetone, or kerosene to clean his product.
- When disposing of this product, treat it as industrial waste and never heat or incinerate it at 100 °C or higher.

Regulations and Standards

FH-505□

Using Product Outside Japan

If you export (or provide a non-resident with) this product or a part of this product that falls under the category of goods (or technologies) specified by the Foreign Exchange and Foreign Trade Control Law as those which require permission or approval for export, you must obtain permission or approval or service transaction permission) pursuant to the law.

U.S. California Notice:

This product contains a lithium battery for which the following notice applies: Perchlorate Material - special handling may apply.

See "www.dtsc.ca.gov/hazardouswaste/perchlorate".

Conformance to KC Standards

Observe the following precaution if you use this product in Korea.

사 용 자 안 내 문 이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

• Guidance for users

This product meets the electromagnetic compatibility requirements for business use. There is a risk of radio interference when this product is used in home.

WEEE Directive



Dispose of in accordance with WEEE Directive

Conformance to EC/EU Directives and UK Legislation

The product is compliant with the standards below:

• EC Directive 2004/108/EC (Until April 19 2016) / EU Directive 2014/30/EU (After April 20 2016) / UK legislation 2016 No 1091 Electromagnetic Compatibility Regulations 2016 EN61326-1 Electromagnetic environment: Industrial electromagnetic environment (EN/IEC 61326-1 Table 2)

- Also, the following condition is applied to the immunity test of this product.
- If the level of disturbance of the video is such that characters on the monitor are readable, the test is a pass.
- This product complies with EC/EU Directives. EMC-related performance of the OMRON devices that comply with EC/EU Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed.
- The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.
- If there is a need to respond to the EC/EU directive and UK legislations, please use by an analog RGB output.

Conformance to UL Standards

This product complies with UL Standards.

• UL61010-2-201

FH-SMDA-GS050B

Using Product Outside Japan

If you export (or provide a non-resident with) this product or a part of this product that falls under the category of goods (or technologies) specified by the Foreign Exchange and Foreign Trade Control Law as those which require permission or approval for export, you must obtain permission or approval or service transaction permission) pursuant to the law.

Conformance to KC Standards

Observe the following precaution if you use this product in Korea.

```
사 용 자 안 내 문
이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서
가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.
```

Guidance for users

This product meets the electromagnetic compatibility requirements for business use. There is a risk of radio interference when this product is used in home.

Conformance to EU Directives and UK Legislation

The product is compliant with the standards below:

• EU Directive 2014/30/EU/UK legislation 2016 No 1091 Electromagnetic Compatibility Regulations 2016 EN61326-1 Electromagnetic environment: Industrial electromagnetic environment (EN/IEC 61326-1 Table 2)

- This product complies with EC/EU Directives. EMC-related performance of the OMRON devices that comply with EC/EU Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed.
- The customer must, therefore, perform the final check to confirm that devices and the overall ma- chine conform to EMC standards.

Related Manuals


The followings are the manuals related to this manual. Use these manuals for reference.

Name of Manual	Cat. No.	Model	Purpose	Contents
Vision System	3648743-1	FH-2002	To confirm the safety and	Describes the definitions of
FH Instruction Sheet		FH-2002-00	usage precautions of the	basic terms, meaning of
		FH-5002	Vision System FH series	signal words, and precautions
		FH-5002-00	Sensor Controller.	for correct use of FH series in
				the manual.
Vision System	3102269-4	FH-2000	To confirm the safety and	Describes the definitions of
Ell Instruction Chast		FH-2000-00	usage precautions of the	basic terms, meaning of
FH Instruction Sheet		FH-5000	Vision System FH series Sensor Controller.	signal words, and precautions for correct use of FH series in
			Sensor Controller.	the manual.
	3290410-0	FH-SMDA-GS050B	To confirm the safety and	Describes the definitions of
3D Vision Sensor	3230410-0	TTT-GMDA GGGGGD	usage precautions of the 3D	basic terms, the meaning of
FH-SMDA Instruction Sheet			Vision Sensor FH-SMDA.	signal words, and precautions
				for correct use of 3D Vision
				Sensor FH-SMDA in the
				manual.
FH Application Software FH-	5665477-6	FH-UM3D1	To confirm the safety and	Describes the definitions of
UM3D1 Instruction Sheet			usage precautions of the FH	basic terms, product
			Application Software FH-	specifications, how to use,
			UM3D1. When User want to	meaning of signal words, and
			know about the hardware	precautions for correct use of
			specifications or to setup the	FH Application Software FH-
			FH Application Software FH-UM3D1.	UM3D1 in the manual.
Vision System FH series	Z446	FH-505□	When User want to know	Describes the soft functions,
3D Robot Vision Application	2440	FH-SMDA-GS050B	about the FH series 3D robot	setup, and operations to use
Construction Guide			vision system.	FH series 3D robot vision
				system.
Vision System FH series	Z436		When User want to know	Describes FH series 3D robot
Hardware Setup Manual for			about the Hard-ware	vision system specifications,
3D Robot Vision			specifications or to setup the Sensor Controller of the FH	dimensions, part names, I/O
			series 3D robot vision	information, installation
			system.	information, and wiring
V				information.
Vision System FH series Processing Item Function	Z445		When User confirm the	Describes the software
Reference Manual for 3D			details of each processing	functions, settings, and
Robot Vision			items at the create the measurement flow or	operations for using FH series 3D robot vision system.
			operate it.	3D TODOL VISION System.
Vision Sensor FH Series 3D	Z451		When User calibrate 3D	Describes 3D vison sensor
Robot Vision AOS Camera	2431		vison sensor itself.	AOS camera calibration
Calibration Operation Guide				operation by using camera
				calibration target.
Vision System FH/FHV	Z447		When connecting FH series	Describes communication
series			3D robot vision system to the	settings and sample programs
Robot Connection Guide			robot	for picking applications that
OMRON TM Series Edition				connect FH series 3D robot
Vision Contant EU/EUV				vision system to the robot.
Vision System FH/FHV series	Z448			
Robot Connection Guide				
OMRON Viper Series				
Edition				
	ı	ı	<u> </u>	<u> </u>

	1	7		
Vision System FH/FHV series Robot Connection Guide FANUC Corporation Edition	Z449			
Vision System FH/FHV series Robot Connection Guide DENSO WAVE INCORPORATED Edition	Z458			
Vision System FH/FHV series Robot Connection Guide ABB Corporation Edition	Z459			
Vision System FH/FHV series Robot Connection Guide YASKAWA Corporation Edition	Z460			
Vision System FH/FHV series Robot Connection Guide UNIVERSAL ROBOTS Edition	Z463			
Vision System FH/FHV series Robot Connection Guide NACHI-FUJIKOSHI Corporation Edition	Z464			
Vision System FH/FHV Series User's Manual	Z365	FH-2000 FH-2000-00 FH-5000	When User want to know about the FH/FHV series.	Describes the soft functions, setup, and operations to use FH/FHV series.
Vision System FH/FHV series Processing Item Function Reference Manual	Z341	FH-5aca-ac FH-Laca-ac FH-Laca FHV7a-acaca-C FHV7a-acaca-Sac FHV7a-acaca-Sac	When User confirm the details of each processing items at the create the measurement flow or operate it.	Describes the software functions, settings, and operations for using FH/FHV series.
Vision System FH/FHV Series User's manual for Communications Settings	Z342	FHV7a-aaaa-Haa FHV7a-aaaa-Haa-aa	When User confirm the setting of communication functions.	Describes the functions, settings, and communications methods for communication between FH/FHV series and PLCs. The following communications protocol are described. Parallel, PLC Link, EtherNet/IP, EtherCAT, and Non-procedure.
Vision System FH series Macro Customize Functions Programming Manual	Z367	FH-2000 FH-2000-00 FH-5000 FH-5000-00 FH-L000 FH-L000-00	When User operate or programming using Macro Customize functions.	Describes the functions, settings, and operations for using Macro Customize function of the FH series.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Rev. Code	Rev. Date	Revision Contents
01	Feb. 2021	Original product
02	Jun. 2021	Corrected mistakes.
03	Jan. 2022	Added to "Related Manuals".
04	Sep. 2022	Revisions for adding safety precautions regarding security.
		Added to "Related Manuals".
05	Feb. 2023	Revisions for update "Precautions for Safe Use", "Precautions
		for Correct Use", "Regulations and Standards", and "Related
		Manuals".
		Revisions for update camera cables model.
		Added FZ-MEM16G
06	Jun. 2024	Revisions for update "Precautions for Safe Use", "Precautions
		for Correct Use", and "Related Manuals".
		Additional support for FH-5051 and FH-5052.

1. Overview

1.1. Overview

This document describes procedures for settings required for constructing 3D robot vision applications by connecting the Vision Sensor FH (hereafter referred to as Vision Sensor) to the robot controller.

Utilizing this document and the "Vision System FH/FHV series Robot Connection Guide" listed in the "Related Manuals" at startup, you can reduce the man-hours required to connect the Vision Sensor to your robot controller, set the Vision Sensor, and create robot programs.

Robot Vision applications described in this document are as follows.

Application	Description
Picking application with on-	Robot vision system with a camera mounted on the robot arm.
hand camera	The robot can pick and place randomly placed workpieces.

1.2. Target Audience

The target reader for this document are persons responsible for developing 3D Robot Vison Applications by connecting a vision sensor and a robot controller. Additionally, the reader needs to have the capability to operate and program robots.

1.3. Work Flow

Please follow the flow below for constructing robot vision applications.


For the robot settings, please refer to the *Vision System FH/FHV series Robot Connection Guide* listed in the *Related Manuals* according to the robot to be connected.

	Creating Data Set for the Robot Vision	This document Section 6
_		
	3D Sensor Software Installation	This document Section 7
	V	
	Robot Controller Communication setting	Robot Connection Guide (Section 3.1)
	▼	
	Connecting the Vison Sensor and the robot Controller	Robot Connection Guide (Section 3.2)
	Vision Sensor Setting for Robot Vision	This document Section 8
	▼	
	Designing robot program	Robot Connection Guide (Section 6)

2. System Configuration

This section describes the system configuration and target devices to construct robot vision applications. Please refer to the *Vision System FH/FHV series Robot Connection Guide* listed in the *Related Manuals* for detail system configuration for each robot system.

2.1. System Configuration



2.2. Applicable Devices

The following is a list of target devices.

For details on robot-related items, refer to the *Vision System FH/FHV series Robot Connection Guide* (hereinafter also referred to as the *Robot Connection Guide*) corresponding to each robot listed in the *Related Manuals* pages.

Device name	Manufacture	Name	Model	Remarks
Vision Sensor	OMRON	Vision Sensor FH	FH-505□	FH-5052: Ver.6.60 or
		Series		higher
				FH-5051: Ver.6.51
				FH-5050: Ver.6.40 to
				Ver.6.51
				Controllers other
				than the FH-505□ are
				not supported.
3D Camera	OMRON	3D vision sensor	FH-SMDA-GS050B	
Camera	OMRON	Ethernet cable super	FHV-VNBX2□M	
cable		bending resistance	FHV-VNLBX2□M	

Camera I/O	OMRON	I/O cable super bending	FH-VSDX-BX□M	
cable		resistance	FH-VSDX-LBX□M	
Calibration	OMRON	Handeye Calibration	FH-XCAL-R	
target		Target		
		Camera Calibration Target	FH-XCAL-S	
3D software	OMRON	3D Robot Vison Software	FH-UM3D1	3D robot vision
		Installer		application and 3D
				camera driver
Robot	OMRON	collaborative robot	RT6-0007000	For details, refer to
controller		TM5-700		the Robot
		TM5-900	RT6-0009000	Connection Guide
				listed in Related
				Manuals.
		Vertical multi-joint robot	1720□-36000	For details, refer to
		Viper 650	1720□-36020	the Robot
			1720□-36010	Connection Guide
		Viper 850	1720□-38000	listed in Related
			1720□-38020	Manuals.
			1720□-38010	
	FANUC	Vertical multi-joint robot	R-30iB Mate	For details, refer to
	Corp.	LR Mate 200iD/4S		the Robot
				Connection Guide
				listed in Related
				Manuals.
PC software	OMRON	Data set output tool for 3D		Ver.1.0.0
		robot vision		You can download it
				from the purchaser
				limited service.
				Please contact our
				branch or sales
				office.
	OMRON	Robot programing		Refer to the Robot
		environment		Connection Guide fo
				each robot.
	FANUC	Robot programing		Refer to the Robot
	Corp.	environment		Connection Guide for
				each robot.
Switching	OMRON	Industrial switching hub	W4S1-□□□	Recommended
hub				product
USB flash	OMRON	USB flash drive	FZ-MEM16G	Recommended
drive				product



Precautions for Correct Use

Do not use any device except those mentioned above for each device of the system configuration.



Additional Information

This document does not cover operations, installation, and wiring methods for each device. For details, refer to manuals noted in Reference Manual.


3. Configuration of the Application

3.1. Specification of the Sensor

Specification


Refer to the section 3-2-1 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

•Component Names and Functions



	N	lame	Description
1	2D lighting unit		Lighting for 2D measurement is arranged to illuminate the light.
2	3D lighting u	nit	Pattern lighting for 3D measurement is arranged to illuminate the light.
3	Imaging unit		Captures images.
	Connector 1	or camera I/O	Use this connector when connecting the camera with a power supply or an
4	cable		external device using a camera I/O cable.
			Dedicated camera I/O cable: FH-VSDX-BX / FH-VSDX-LBX)
-	Connector for camera cable 5 (Ethernet cable)		Use this connector when connecting the camera with a FH sensor controller
5			using an camera cable (Ethernet cable).
			Dedicated camera cable (Ethernet cable): FHV-VNBX2 / FHV-VNLBX2)
	Operation	PWR (Green)	Lights while power is supplied.
	indicator	LINK (Green)	Lights when connected with Ethernet equipment.
		ACT (Yellow)	Blinks while communicating with an Ethernet device.
		WARM UP	Lights from startup to completion of warming up. Turns off after warming
6		(Yellow)	up.
		ERR (Red)	Lights when an error occurs.
			For the error (system error), refer to the Camera Image Input AOS in the
			Vision System FH series Processing Item Function Reference Manual for
			3D Robot Vision (Cat. No. Z445).

•Measurement Range and Field of View



Dimensions

Refer to the section 3-2-1 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

3.2. Workpiece

Use the following information as a guide to determine whether a part is measurable. Note that this guide is not a guarantee. Test thoroughly to make sure that it is measurable.

Characteristics	Measurable Unmeasurable	
Surface	Matte to weak luster	Mirror surface, strong gloss,
characteristics		transparent, translucent
Characteristics	Pattern reflects moderately from	Pattern is completely reflected or
	all surface	absorbed
Surface shape	Narrowest width of the surface	Holes and steep unevenness,
•	is more than 10 mm	dominant width is less than 10 mm.
	Shapes on which pattern light	Pattern light is interrupted
	does not break or warp	
Exterior size	Dimensions ≥ 40 x 40 mm	Dimensions < 40 x 40 mm
	Thickness ≥ 5 mm	Thickness < 5 mm
	Area and height required to	Surface area and height for which 3D
	obtain sufficient 3D features for	features required for recognition
	recognition	cannot be obtained

3.3. Container

Examples of containers that are supported or not supported by the 3D robot vision software are shown below.

	Container shape examples	Conditions
Supported	Box container	Edge thickness: 10 mm or more
		Maximum size:
		Approx. 400 × 300 mm
		Size that fits in the field of
		view of the 3D Vision Sensor
		Minimum size:
		Edge width: 10 mm or more
		Container inner dimensions:
		10 x 10 mm or more
		Container color:
		Colors that can be detected
		by 2D search
Not	Partitioned Part rack Mortar-shape	d Container shapes with internal
supported		partitions or gradients cannot be
		registered.
		For information on whether you can
		customize the software to support
		these shapes, please contact your
		sales representative.
	Transparent Mesh rack	Container shapes as seen from
	or translucent	directly above the opening or with
	144	colors that cannot be detected by
		2D search are not supported.

3.4. Supported Robots

Refer to the *Robot Connection Guides* in "Related Manuals". For connection to other robots, please contact your sales representative.

4. Equipment Installation Ovewrview

4.1. Mounting

Attach the camera to the 6th axis of the 6-axis articulated robot using a jig. Refer to the section 5-5-2 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

4.2. Wiring

Wire the signal line of the camera I/O cable (FH-VSDX-BX / FH-VSDX-LBX: sold separately) with a crimp terminal. Insulate unnecessary signal lines and avoid contact with other signal lines. Refer to the section 5-5-2 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

4.3. Connecting

Connect the camera cable (Ethernet cable FHV-VNBX2 / FHV-VNLBX2: sold separately) to the Ethernet connector on the 3D vision sensor. Then connect it to the top of the two Ethernet connectors on the sensor controller. Refer to the section 5-5-2 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

4.4. Camera Cable Mounting

To prevent the cables from being caught in the rotating robot, connect them with a sufficient clearance, taking into account the minimum bending radius.

To prevent the connectors from interfering with the robot, adjust the rotation angle of the robot. Refer to the section 5-5-2 in the *Vision System FH Series Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436).

4.5. Start and Stop Sequence

Turn ON the power of the 3D Vision Sensor at the same time as or before you turn ON the power of the FH Controller. If the FH Controller starts up first, it will not be able to communicate with the 3D Vision Sensor.

Also, because scene data is large, confirm that saving of the data is completed before you turn OFF the Controller.

5. Startup Procedure

This section describes the work flow, preconditions, and what can be achieved by Startup Procedures in each section.

5.1. Preconditions

The following conditions shall be satisfied.

- · The installation, wiring, and operation verification for each device have been finished.
- · Warmup of 3D vision sensor is completed.
- Robot is operated in the robot base coordinate and no tool offset is set.




Additional Information

- This document does not provide operations, installation, and wiring methods for each device. For details, refer to manuals noted in *Related Manuals*.
- As a guide, the warmup time of the 3D Vision Sensor is about 15 minutes after power ON. For details, refer to *Precautions for Correct Use* in the following manual. *Vision System FH* series *Hardware Setup Manual for 3D Robot Vision* (Cat. No. Z436)
- For the setup of the robot, refer to the *Vision System FH/FHV series Robot Connection Guide* for the robot to connect.

5.2. What You Can Do by This Startup Procedure


5.2.1. 3D Robot Vision Software Installation

Factory default Vision Sensor doesn't have software for 3D measurement. Please follow the procedure in section 7 to install a 3D Software and camera driver to the Vision Sensor.




5.2.2. Connecting the Vision Sensor to the Robot Controller

The procedures to load the sensor controller project data (including scene data) into the Vision Sensor and configure the network are described in the 7.2 and 7.3, respectively. For the setup and connection to the robot controller, refer to the *Vision System FH/FHV* series Robot Connection Guide for the robot to connect listed in the Related Manuals in this manual.



5.2.3. Setting Vision Sensor


When following the procedures in section 8 you can complete settings for the Vision Sensor required for applications that are calibration between camera and robot, and controlling the robot from the Vision Sensor's operation.



5.2.4. Designing Robot Program

The robot program implementation procedure for controlling the Vision sensor (changing scenes, executing measurement) is described in the section 6 of 'Vision System FH/FHV series Robot Connection Guide'.

Refer to the document corresponding to each robot.





Precautions for Correct Use

The implementation procedures for robot programs noted in the 'Vision System FH/FHV series Robot Connection Guide' are for reference only. You must design, implement, and test actual robot program operation based on the used environment and robot applications.

6. Creating Data Set for the Robot Vision

This section describes the work flow for creating a data for the vision sensor (sensor controller project data) and a robot program (sample program) for the robot controller.

6.1. Creating Data Sets

Use the Data set output tool for 3D robot vision to output the following data sets.

You will use the sensor controller project data that you create here in 7.2. For details on the scene data included in the sensor controller project, refer to 8.3.

For details on the robot program, refer to the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals* in this manual.

	Output data	Description
1	Sensor controller project data	Scene templates, communication command
		macros, user dialogs, etc., that are required
		to construct the 3D robot vision application
2	Robot program	Setup programs for setting up the
		application, sample programs for executing
		the application

Follow the steps below to create the data sets for robot vision.




Precautions for Correct Use

 The operating environment of the Data set output tool for 3D robot vision is Windows 10 64-bit.

Step	Description	Window image, diagram
1	Open the folder on your PC where the Data set output tool for 3D robot vision is stored. Launch the dataset output tool for 3D robot vision by double clicking RobotSettingTool.exe.	3DRobotSettingTool_eng × → 3DRobotSettingTool_eng ∨ → TMROBOT (E:) → TMROBOT (E:) → RobotSettingTool_eng → Inanguage → 3DRobotSettingTool_eng → Inanguage → 3DRobotSettingTool.exe

2 Select a robot manufacturer to connect from the combo box.



△Caution

Select the actual robot to connect. Selecting a wrong robot causes the Vision Sensor to output incorrect command values to the connected robot, which may result in unexpected robot movement. Sensor controller projects that the tool outputs cannot be used commonly between different robots.



Click [Output] after selecting Output Output path the output path for the data Close set. Click [OK] when the "Check" 4 Check Dialog is displayed after the data set was output. Outputting data is complete. Check that a folder was created 20200624161356 × with a name of "year, month, Name TMROBOT (E:) day, hour, minute, and second" FHdata 20200624161356 in the specified output path and RobotProgram RobotSettingTool_jpn there are "FHdata" and "RobotProgram" in it. The FHdata folder stores the sensor controller project files for 3D robot vision. The RobotProgram folder stores the robot program. Copy the folder that contains the output FHdata and RobotProgram to a USB flash drive or other media.

7. 3D Sensor Software Installation

This section describes procedures to install 3D Sensor Software to the Vision Sensor. Before installation, please disconnect the 3S sensor head from the Vison sensor. Please follow the flow below for the installation.

7.1. Installing and Uninstalling the 3D Robot Vision Software

This section describes the procedures for upgrading the software of the FH sensor controller with the FH-UM3D1.

Please perform the software version upgrade only after confirming the operating procedures and cautions. After upgrading, if you want to return to the previous version, use the Version upgrade tool (Ver. 6.11 or higher) and install the applicable FH sensor controller software.

For troubleshooting for Installing and Uninstalling, refer to 7.1.4.



Precautions for Correct Use

- Keep a backup of the scenes and other data created with older versions before you update the software. They may become unusable due to incompatibility.
- For how to back up the data, refer to *Backing up Sensor Controller setting data* in the following manual. *Vision System FH/FHV Series User's Manual* (Cat. No. Z365)



Precautions for Correct Use

- FH-UM3D1 can be used for version upgrade of one FH Sensor Controller.
- Keep the FH-UM3D1 device in a safe place as it will be needed when using again or repairing a controller.


Do not make any modifications to the files or file structure of the FH-UM3D1. It may cause the device to no longer function correctly.

7.1.1. Applicable Devices and Device Configuration

The devices for which there is FH-UM3D1 support are as follows.

Manufacturer	Name	Model	Version
OMRON	FH sensor controller	FH-505□	FH-5052: Ver.6.60 or higher
			FH-5051: Ver.6.51
			FH-5050: Ver.6.40 to Ver.6.51
			Controllers other than the FH-
			505□ are not supported.

Connect each device as follows.



Manufacturer	Name	Model	Version
OMRON	FH-UMAI version up tool	FH-UM3D1	
OMRON	Vision sensor	FH-505□	
	USB mouse		
	LCD monitor		
	Power supply		



- Do not connect anything other than those included in the above configuration to the FH sensor controller during version upgrade. If a USB switch, etc. is connected, the FH sensor controller may not operate properly after the version upgrade.
- Do not insert any external storage device other than USB flash drive or SD card that contains the Version update tool software in the FH Sensor controller. The version upgrade may not be completed normally.

7.1.2. Software Installation



Precautions for Correct Use

- Do not remove the FH-UM3D1 from the FH sensor controller during the version upgrade. It may cause the version upgrade to fail.
- Do not turn off the power to the FH Sensor Controller during the version upgrade. It may cause the version upgrade to fail.

Follow the steps below to install the software.

Step	Description	Window image, diagram
1	Make sure the FH-UM3D1 is inserted in the FH Sensor Controller when it is started up. The Language Setting dialog will be displayed the first time the FH-UM3D1 is used. In the Language Setting dialog, select the language and click OK.	Language Setting Select language of the system. Language: Japanese OK
2	If the license file has already been generated, the following dialog will be displayed. Click OK .	FH-UM3D Firmware upgrade tool Ver.1.00 The production of license is accomplished. Press "OK" button to start installation. OK

If the license file has not already been generated, the following dialog will be displayed. Click **OK**.


The following dialog will be displayed. Click **OK**.

If you click **Cancel**, the following dialog will be displayed. Click **OK**. The license file creation will be canceled and the FH Sensor Controller will be restarted.

The following dialog will be displayed. Click **Execute**. The Version upgrade will be started.


If you click **Cancel**, the Version upgrade is cancelled and the FH Sensor Controller will be restarted.


If you click Language Setting, the Language Setting dialog will open. Select your desired language and click OK. The dialog will change to the selected language. If you click Cancel it will revert to the previous language.












When upgrading, the FH sensor controller may restart more than once.



Precautions for Correct Use

Do not remove the FH-UM3D1 until the version upgrade is completely finished.


If the following dialog appears, select Install this driver software anyway. If the dialog below does not appear, proceed to the next step.






Precautions for Correct Use

If you select **Don't install this driver software**, the process will proceed without updating the driver. If you mistakenly select this, the following dialog will appear. Click **OK** to display the same dialog screen will appear again during the process. In which case select **Install this driver software anyway**.




Depending on the configuration of the FH sensor controller, Touch panel drivers may also be installed. If the following dialog appears, select **Install**. If the dialog below does not appear, proceed to the next step.





If you select **Don't install**, the process will proceed without updating the driver. If you mistakenly select this, the following dialog will appear several times. Click **OK**. After that, please proceed to step 9 and execute the version upgrade procedure again.



7 When upgrading, the FH sensor controller may restart more than once.



Precautions for Correct Use

Do not remove the FH-UM3D1 until the version upgrade is completely finished.

The following dialog will appear. Remove the FH-UM3D1 from the FH sensor controller and click **OK**.



- 9 The FH controller will restart.
- When the FH sensor controller starts, a dialog as shown on the right will appear to confirm that you are about to perform network configuration for the 3D Vision Sensor. Click **OK**.

When you click **OK**, if the application software for the FH sensor controller is running, a dialog as shown on the right will appear to prompt you to close the FH application.

In the FH application software, click **End** from the **File** menu to close the FH application software, and then click **OK** in the dialog.






If other processing such as firmware update is running, wait until it completes before you close the FH application software.

When you close the FH sensor controller application software, the window keyboard may terminate abnormally. If the window keyboard terminates abnormally, there will be a delay in response to your mouse operation, along with an abnormal termination notification as shown on the right. Close the abnormal termination notification to recover from the symptom.



11 When a dialog as shown on the right appears to notify that you are about to restart the sensor controller, click **OK**.



A command prompt as shown on the right appears, which shows the progress of automatic camera driver installation and Ethernet communications configuration. When the processing is completed, the sensor controller will restart automatically.

```
Start the installation in progress.

GigE Driver initial lation in progress.

The reasested service has already been started.

More held is available by typing NET HELPASO 2182.

Network configuration in progress. [Tucal Area Connection"]

Network configuration in progress. [Tucal Area Connection"]

Description of interface "Local Area Connection"]

Ourrent NICT configurations. [Tucal Area Connection 2"

DEP embled:

Default Gateway:

Ourrent NICT configurations.

Configuration for interface "Local Area Connection 2"

DEP embled:

DEP e
```



- Since this processing initializes the Ethernet communications settings, the FH sensor controller may fail to communicate with the 3D Vision Sensor after the restart. If it fails to communicate with the 3D Vision Sensor, restart the system again.
- Since this processing initializes the Ethernet communications settings, the FH sensor controller may not be able to communicate with external devices. If so, you need to reconfigure the Ethernet communications settings. For details on setting the conditions for Ethernet communications, refer to the Vision System FH/FHV Series User's Manual for Communications Settings (Cat. No. Z342).

If the dialog shown on the right is displayed for installation of the driver in the middle of step 12, select **Install**. If the following dialog does not appear, no operation is required.





Precautions for Correct Use

 Select Don't install to proceed without updating the driver. If this is not the case, from the Windows start menu, select OMRON – FH-UM3D1 and click ReInstal after restarting in step 12.

This will complete the Version upgrade.

Connect the 3D vision sensor and restart FH Sensor Controller.

7.1.3. Software Uninstallation

This section describes the procedure to uninstall the 3D robot vision functions from the FH sensor controller and restore the standard FH sensor controller Ver. 6.4.0. Performing the uninstallation operation disables the dedicated processing items for the 3D Vision Sensor and 3D robot vision. To reinstall the 3D robot vision functions in this state, follow the version upgrade procedure again.



Precautions for Correct Use

Performing uninstallation disables the scene group data, scene data, and window layout that you have used. Before you perform uninstallation, back up the settings of the FH sensor controller. For how to back up the data, refer to *Backing up Sensor Controller*

setting data in the following manual. Vision System FH/FHV Series User's Manual (Cat. No. Z365)

No. Z365)

1 From the Windows Start menu, select
OMRON - FH-UM3D1 and click Uninstall.

A dialog as shown on the right appears to confirm that you are about to start uninstallation.

Click **OK** to start uninstallation.


Click **Cancel** to cancel the uninstallation and end the processing.

When you click **OK**, if the application software for the FH sensor controller is running, a dialog as shown on the right will appear to prompt you to close the FH application.

In the FH application software, click **End** from the **File** menu to close the FH application software, and then click **OK** in the dialog.


When you close the FH sensor controller application software, the window keyboard may terminate abnormally. If the window keyboard terminates abnormally, there will be a delay in response to your mouse operation, along with an abnormal termination notification as shown on the right. Close the abnormal termination notification to recover from the symptom.

When a dialog as shown on the right appears to notify that you are about to restart the sensor controller, click **OK**.










A command prompt as shown on the right appears, which shows the progress of automatic uninstallation of the camera driver, deletion of dedicated processing items for 3D robot vision, installation of FH application software Ver. 6.40, etc. When the processing is completed, the sensor controller will restart automatically.



This will complete the uninstallation.




Precautions for Correct Use

Performing uninstallation disables the scene group data, scene data, and window layout
that you have used. After you perform uninstallation, initialize the settings of the FH
sensor controller before use. For how to initialize the FH sensor controller, refer to
Initializing the Controller in the following manual. Vision System FH/FHV Series User's
Manual (Cat. No. Z365)

7.1.4. Troubleshooting

When this occurs	Possible cause	Corrective action
The Version upgrade tool does	The files in the FH-UM3D1	Perform the Version upgrade
not start.	may be corrupted.	procedure again.
	At startup, there may be a	If it does not start after the
	delay in recognizing FH-	above actions, please contact
	UM3D1, and the Version	us.
	upgrade tool may have failed	
	to load.	

When this occurs	Possible cause	Corrective action
The FH controller does not	A power failure may have	Turn off the power of the FH
restart.	occurred during installation,	sensor controller and restart
	and the hardware of the FH	it.
	Sensor Controller may be	If the above does not work,
	damaged.	the file or hardware may be
		damaged.
		Please contact Omron.
	The files in the FH Sensor	Perform the Version upgrade
	Controller may be corrupted.	procedure again.
	The version upgrade may	If the above does not work,
	have failed due to the	the file or hardware may be
	insertion / extraction of FH-	damaged.
	UM3D1.	Please contact Omron.
The camera or I/O do not work	Some files may not have	Perform the Version upgrade
properly after the version	been updated due to FH-	procedure again.
upgrade.	UM3D1 insertion / removal	If the above does not work,
	while the FH sensor	the file or hardware may be
	controller was restarting.	damaged.
		Please contact Omron.
After version upgrade, the FH	You may have selected Do	Perform the Version upgrade
sensor controller does not start	not install in the driver	procedure again.
normally.	installation confirmation	If the above does not work,
	dialog during the version	the file or hardware may be
	upgrade. Some files may not	damaged.
	have gotten updated.	Please contact Omron.
	It is possible that the power	
	was turned off without	
	pressing the OK button when	
	the version upgrade	
	complete message was	
	displayed. Some files may	
	not have gotten updated.	
	There was a delay in	
	recognizing the FH-UM3D1	
	while restarting the FH	
	sensor controller, and some	
	files may not have gotten	
	updated.	



When this occurs	Possible cause	Corrective action
The following dialog is	If an error occurs in the	Please contact Omron.
displayed.	controller, the dialog will be	
FH-UM3D Firmware upgrade tool Ver.1.00	displayed.	
Failed to read sensor controller information. Possible hardware failure.		
Please contact out company. Press "OK" button restart.		
ОК		
Ептог		
Failed to read sensor controller information. Possible hardware failure.		
Please contact our company. Press "OK" button to restart.		
ОК		
The following dialog is	If an error occurs in FH-	Please contact Omron.
displayed.	UM3D1, the dialog will be	
FH-UM3D Firmware upgrade tool Ver.1.00 License file creation failed.	displayed.	
Possible hardware failure. Please contact out company.		
Press "OK" button restart.		
ОК		
The following dialog is	If you use a licensed FH-	Use FH-UM3D1 with the
displayed.	UM3D1 with an FH sensor	correct license file.
FH-UM3D Firmware upgrade tool Ver.1.00	controller that is different	
The license validation failed. The license file is for a different sensor controller.	from the one used when the	
Please insert FH-UM3D with correct license. Press "OK" button to restart.	license was created, the	
ОК	dialog will be displayed.	
The following dialog is	If the version upgrade fails,	Perform the Version upgrade
displayed.	the dialog will be displayed.	procedure again. If the dialog
Gror ▼		is displayed every time,
Failed to upgrade firmware. Remove FH-UM3D, and press "OK" button. The system will reboot with the current firmware.		please contact Omron.
ОК		
(Failed to Update firmware.		
Remove FH-UM3D, and press "OK"		
button. The System will reboot with		
the current firmware)		


When this occurs	Possible cause	Corrective action
The following dialog is	If you remove the FH-UM3D1	Connect FH-UM3D1 again
displayed.	while updating the driver, the	and press the OK button. The
Please do not remove FH-UM3D until complete.	dialog will be displayed.	Version upgrade will continue.
(Please do not remove FH-UM3D		
until complete)		
The following dialog is	If the Ethernet	To start the configuration
displayed.	communications	again from the beginning,
Confirmation	configuration fails, the	click the Yes button.
Network configuration failed. Would to try again after the reboot ?	following dialog will be displayed.	To leave the settings as they are, click the No button. Whichever you choose, the
Yes No		sensor controller will restart.

7.2. Loading the Sensor Controller Project

An application template that include scene data, environment variables and macros is loaded from the sensor controller project data. The sensor controller project data is being prepared separately according to each robot. Use a sensor controller project that matches the robot type.

Please follow the procedures below to load the configuration data.

Step	Description	Window image, diagram
------	-------------	-----------------------



7.3. Configuring the Network (Ethernet Communications)

The IP address of Vision sensor and 3D sensor head is as shown below.

Please connect 3D vison sensor to Ethernet1.

Then, connect the robot controller and other communication equipment to Ethernet2. For how to check the network settings of the robot controller and the connection with the FH sensor controller, refer to the *Vision System FH/FHV series Robot Connection Guide* for each robot listed in the

Related Manuals in this manual. You can set any IP address for the FH sensor controller Ethernet2.

	IP Address	Net mask	Connect to
Vision Sensor	10.5.5.100	255.255.255.0	3D Sensor head
Ethernet1			
Vision Sensor	10.5.6.100	255.255.255.0	Other equipment
Ethernet2			
3D Vision Sensor	10.5.5.XXX	255.255.255.0	Vision Sensor
	(auto assigned)		Ethernet1



Precautions for Correct Use

- Do not change the settings of the FH sensor controller Ethernet1 as it prevents communications with the 3D Vision Sensor. If you change the communication settings by mistake and find that the sensor controller is not communicating with the 3D Vision Sensor, restore the default settings above.
- Set the settings in section 3 of *Vision System FH/FHV series Robot Connection Guide* " using the above examples of IP addresses.
- Change the IP address and subnet mask settings of the FH sensor controllers
 Ethernet1 and Ethernet2 as necessary so that they have different IP addresses. Setting
 the same IP address may prevent the sensor controllers from communicating correctly.


Setting only the IP address of the FH sensor controller Ethernet2 in the System settings (**Tools - System settings - Communications**) does not reflect the change in the system. To have it reflected in the system, perform the following procedure. If the IP address of Ethernet2 is changed, be sure to follow the procedure below. For details on setting the conditions for Ethernet communications, refer to the *Vision System FH/FHV Series User's Manual* (Cat. No. Z365).

Step Description	Window image, diagram
------------------	-----------------------

1 Configure the Communications Module settings of the FH sensor controller. For details, refer to the following information.
2-5 Non-procedure Communications in Vision System FH/FHV Series User's Manual for Communications Settings (Cat. No. Z342)

2 Set the communication specifications of the FH sensor controller for communications with external devices. Configure the settings in **Address setting 2** only.

After setting, click **Data Save** button of Vision Sensor Main window.



3 Close the FH application software.
In the FH application software, click **End** from the **File** menu.



Have the Ethernet communications settings that you configured in the FH sensor controller reflected in the system.
From the Windows Start menu, select

OMRON - FH-UM3D1 and click NICconfig.
A dialog as shown on the right appears to confirm that you are about to start IP address setting.

Click **OK** to start the IP setting. Click **Cancel** to cancel the IP setting and end the processing.





Precautions for Correct Use


If you cancel the IP setting, the Ethernet communications settings will not be reflected in the system. Start again from Step 4.

When you click **OK**, if the application software for the FH sensor controller is running, a dialog as shown on the right will appear to prompt you to close the FH application.

In the FH application software, click **End** from the **File** menu to close the FH application software, and then click **OK** in the dialog.

When you close the FH sensor controller application software, the window keyboard may terminate abnormally. If the window keyboard terminates abnormally, there will be a delay in response to your mouse operation, along with an abnormal termination notification as shown on the right. Close the abnormal termination notification to recover from the symptom.






When a dialog as shown on the right appears to notify that you are about to restart the sensor controller, click **OK**.



A command prompt as shown below appears, which shows the progress of automatic configuration of the Ethernet communications settings. When the processing is completed, the sensor controller will restart automatically.



The Ethernet communications settings are now reflected in the system.

If the network configuration fails, the following dialog will be displayed.

To start the configuration again from the beginning, click the **Yes** button.

To leave the settings as they are, click the **No** button.

Whichever you choose, the FH sensor controller will restart.



After completing the configuration, follow the instructions in the *Vision System FH/FHV Series User's manual for Communications Settings* (Cat. No. Z342) to check the communications status.

8. Vision Sensor Setting for Robot Vision

This section describes the setting procedures for the Vision Sensor required for constructing robot vision applications.

8.1. Overview

The settings for the Vision Sensor use a special data set for robot vision applications. By loading the sensor controller project according to the procedures in section 6, scene group data and user dialog data are loaded. Thereby, you can start the setting without designing a measurement flow from scratch. Additionally, the Vision Sensor user dialogs equip robot controlling functions such as jog operation and auto-calibration. It contributes to reduce manhour of constructing an application.



Precautions for Correct Use

This section covers the operation to output the grasp points of the detected workpieces in the robot coordinate system. It does not cover the path control (path plan) of the robot, and the grasp error control, placement position recognition, and placement position control of the grasped workpieces.


8.2. Coordinate Systems and Angle Types

This section describes the coordinate system and angle representation used in the processing items to set the sensor settings.

1) Robot coordinate system

This coordinate system deals with the coordinates of the robot. The terms used in the robot coordinate system are shown in the table and figure below.


Coordinate system name	Description
Robot base coordinate system	Origin is based on the robot base.
Local coordinate system	User defined coordinate system
Flange coordinate system	Origin is based on the robot flange center.
Tool coordinate system	
	robot flange.
Camera coordinate system	Origin is based on cameras optical center.




For each coordinate system, the orientation of each axis differs depending on the robot manufacturer and axis configuration. For the detailed definition of the coordinate systems, please refer to the manual for your robot.

2) Camera coordinate system


The coordinate system used by the 3D Vision Sensor. The center of the left-side window of the 3D Vision Sensor is the origin of the camera coordinate system. On the display, X represents the direction toward the right side; Y represents the direction toward the lower side; and Z represents the direction from the front to the back of the paper.






3) CAD coordinate system

The coordinate system of CAD data. It has the origin and directions set in the CAD software, which are defined in individual CAD data. The center of gravity of the CAD data is not necessarily the origin.



4) Latitude and Longitude

The registration range of a 3D Search model can be specified as latitude range and Longitude range. When a model is displayed in the window, the directions of the latitude range and longitude range are defined as shown below.



8.3. Scene Data Configuration

Scene data is assigned to fixed scene per application. When setting it, switch scenes with reference to the following.

No.	Scene name	Description
0	Place_Onhand_6axis	Perform Pick application.
:	:	
125	Calibration _Place_Onhand_6axis_XXX	Perform hand-eye calibration.
	(XXX: Identifier of robot type)	
126	3D_Data_Manager	Register workpiece CAD data, hand(gripper)
		model data and grasp point data. The
		registered data will be referenced by other
		scenes in the same scene group.
127	Camera Calibration AOS	This scene is used to calibrate the camera
		(3D Vision Sensor) using a dedicated
		calibration plate.



Precautions for Correct Use

When you make new scene data for new workpiece or new hand-eye calibration condition, please copy scene No.0 or scene No.125 by using [Function]->

[Scene maintenance]. These two scenes use internal variables to link processing items to enable communications with the robot. If you individually add or delete the processing items, they will not operate properly.

1) No.0 Pick_Onhand_6axis

This scene is for the Picking application.

This scene consist of image input(3D), container detection, work pieces search(3D Search), finding grasp point of work piece and output to the robot.

An output of this scene is sent to the robot and the robot moves to the grasp point.

Copy this scene to adding the new scene for new kind of workpiece.

No.	Processing Unit	Function
0	0.Camera Image Input AOS	Capture an image from 3D camera and reconstruct 3D data (depth map). It also obtains 2D image (gray scale).
1	1.Container Detection	Register the container size (setting mode) and detect the container (run mode).

2	2.3D Search	Searches the work piece in depth image and outputs its 3D coordinate values (X,Y,Z,RX,RY,RZ) in camera coordinate system.
3	3.Grasp Planning	Selecting preferable grasp point (no conflict with container) from searched wok piece. Output grasp point(X,Y,Z,RX,RY,RZ) in robot coordinate.
4	4.Calculation	This unit is used for reflecting total judge of the flow. There is no need to set/modify this unit.
5	5.Result output (Message)	Transmitting the grasp point3D coordinate values (X,Y,Z,RX,RY,RZ) to the robot.
6	6.Robot Info. Log	Log the coordinates of the robot to scene variables to be used for trouble analysis.

2) No.125 Calibtartio_Pick_Onhand_6axis_XXX

This scene is intended to use for the hand-eye calibration between the robot and the Vision sensor. The HandEye calibration unit calculates the hand-eye calibration parameters. The camera coordinate system is converted in the robot coordinate system by using the hand-eye calibration parameters.

To set several different calibration conditions, make copies of this scene.

No.	Processing Unit	Function
0	0.Camera Image Input AOS	Capture an image from 3D camera and
		reconstruct 3D data (depth image). It also
		obtains 2D image (gray scale).
1	⋒ _ 1.Robot Data	Select a robot type to be connected to the
	70	Vision sensor. The information set in this unit
		is referenced form other units (HandEye
		Calibration, Container detection unit).
2 2.3D Search	2.3D Search	Searches a location and posture of the
		calibration target object in 3D space.
3	3.HandEye Calibration	Calculate the hand-eye calibration parameter
P ^{BI}	ph 🚓	with results of 3D Search and robot points and
		postures. The hand-eye calibration
		parameters are referenced from the container
		detection unit

3) No.127 3D_Data_Manager

This scene is used to register/manage the work pieces CAD data, grippers (end effecter) data and grasp points of the work pieces. The 3D Data Manager unit is referenced from processing units (3D Search, Grasp Planning) In another scene in same scene group. It is possible to manage all workpiece data, gripper data and grasp point data belongs to same scene group in one 3D Data Manager unit.

No.	Processing Unit	Function	
0	0.Camera Image Input AOS	Dummy unit. There is no need for setting this unit in this scene.	
1	1.3D Data Manager	 Load the work piece CAD data from file and register the CAD data. Register shape of the gripper (end effector) Register the grasp points of the work pieces. 	


4) No.127 Camera Calibration AOS

This scene is used to correct the geometric parameters of the 3D vision camera (FH-SMDA-GS050B) depending on changes over time or temperature changes. For details, refer to the *Vision System FH Series AOS Camera Calibration Operation Guide* (Cat. No. Z451) listed in *Related Manuals* in this manual.

8.4. User Dialogs


The main window of the Vision Sensor has buttons to launch user dialogs to assist the user to configure settings. Layout 2, which is the default window displayed when you load a sensor controller project for 3D robot vision as described in 7.2, has buttons to start configuration wizards for novice users; Layout 0 has buttons to start configuration without using wizards for experienced users. You can also display the buttons of Layout 0 from the wizard that you start from Layout 2.

For how to switch between the layouts, refer to *Arranging Windows* [Layout Functions] in the *Vision System FH/FHV Series User's Manual* (Cat. No. Z365) listed in *Related Manuals* in this manual.



8.4.1. Layout 0 Window

The main window of the Vision Sensor has buttons to launch user dialogs as shown in the figure below. This section describes buttons that are displayed in the Layout 0 window.



Dialog name	Description		
Robot Operation	Sets the jog operation, target position movement, operation speed,		
	etc.		
HandEye Calib.	Execute the hand-eye calibration (Calibrates a camera and the		
	robot) automatically with operations of the Vision Sensor.		
	The functions and settings of the dialog are described in 8.7.		
Camera Calib AOS	You can operate the Vision Sensor to automatically execute the		
	geometric correction of the 3D Vision Sensor. For details on the		
	functions of the dialog, refer to the Vision System FH Series AOS		
	Camera Calibration Operation Guide (Cat. No. Z451).		
Model Batch Reg.	You can execute or cancel the batch registration of the 3D Search		
	processing item.		
	Use this dialog when you back up or restore scene data.		
Get	When the Vision Sensor can communicate with the robot, you c		
	click the Get button to obtain the current position of the robot.		
	The obtained results are displayed in the Current Robot Pos.		
	column.		
	They are displayed in the X, Y, Z, W, P, and R cells. However, the		
	indication of W, P, and R changes depending on the		
	Representation of pose setting of the connected robot.		
	When Representation of pose is set to ZYX system:		
	$W \rightarrow RX, P \rightarrow RY, R \rightarrow RZ$		
	When Representation of pose is set to ZYZ system:		
	$W \rightarrow RZ, P \rightarrow RY, R \rightarrow RZ$		
Robot Error	If an error occurs in the connected robot, or in communications		
	between robots, this button turns red. Detailed information of an		
	error displayed. Please refer to section 9.2 for detail.		




Precautions for Correct Use

If a robot error occurs, selecting **Clear** from the **Function** menu does not clear the error indication. The error will be cleared when the Vision Sensor successfully communicates with the robot that caused the error, after normal robot status or communications status is recovered.

■Robot Operation

Terms used in this dialog are defined as follows.

Dialog name	Description	
Robot Imaging Position	This is the robot position when imaging (measuring) workpieces. This position is described in the robot base coordinate system.	
Calib. Start Position	Hand-eye calibration base position where the calibration target object is captured around center of the camera view. This position is described in the robot base coordinate system.	





Robot Operation Dialog

Robot Operation Setting Dialog

In the Robot Operation dialog, the following items are provided for basic robot operation from the Vision sensor.

Function	Description			
Jog operation	Execute the jog operation of the robot. By clicking [Jog			
	operation], the robot is operated according to the settings in the jog			
	operation setting.			
	* The robot will not operate even if you are holding down the			
	[Jog operation].			
Target position	The robot performs the jog operation to the position set as a target			
movement	position. The movement amount with one-click action follows the			
	setting value of the jog operation setting.			
Jog operation setting	Settings of jog movement such as single click jog move distance,			
	single click jog rotation angle, robot speed (not enable TM robot)			
	and base coordinate switch.			
	You can choose either "Robot base coordinate" or "Tool coordinate"			
	for Jog Mode.			
	[Robot base] coordinate			
	The coordinate system with reference to the base of the robot. Clicking the log Operation buttons By By and By causes the robot.			
	Clicking the Jog Operation buttons Rx, Ry, and Rz causes the robot			
	to rotate around the X, Y, and Z axes, respectively.			
	[Tool] coordinate The coordinate system with reference to the position and posture of the robot flange. Clicking the Jog Operation buttons Rx, Ry, and Rz causes the robot to rotate around the X, Y, and Z axes, respectively.			





*Initial setting of the Robot Speed is 1%
Depending on the robot, a timeout may occur. Set an appropriate operation speed in consideration of safety.

Comm Setting

Time out between Vision Senor and Robot Controller is set here. The setting range for **Timeout** is 1,000 to 60,000 ms.

- Clicking [Jog operation] or [Robot move] drives the robot. Operate
 the robot in the state whereby pressing the [Emergency stop]
 button can stop its motion anytime.
- Please set safety robot operation speed on the robot controller.
 Robot speed setting from Vision Sensor is not reflected to robot controller.



 Depending on the model of the robot, you cannot change the robot speed setting in **Speed (%)** in the Robot Operation Edit window.
 On the robot side, set the speed to the minimum and check the operation in advance.

When the robot moves in the Z-axis direction, check its motion by visual observation and not by camera image.





Precautions for Correct Use

- These features are only available in a connection status that is established between the Vision Sensor and the robot controller with TCP no-procedure protocol invoked by steps in the Robot connection guide listed in section 7 and the Setup program is running in the robot controller.
- Even if the robot controller changes the reference position from the flange of the tool coordinate system, it will not be reflected to the jog operation setting of the Vision Sensor.
- External trigger inputs or communications with outside the system will be disabled when operating the robot.
- Operations except for the Main Window of the Vision Sensor such as opening setting screens for processing units is not executed.
- If communication was disconnected during operations of the user dialog, operations of the Vision Sensor may be unavailable for the time period set for communication timeout (Default: 60,000 [ms]) in Communication settings. Please change the value as necessary.



Precautions for Correct Use

The operations of the user dialogs described here are effective only when the Vision Sensor is connected to the robot according to the procedures described in the *Robot Connection Guide* for each robot listed in Related Manuals in this manual, and when the setup program is running on the robot side.

■Model Batch Registration

You can use batch model registration to register and unregister all 3D Search unit models that you set in 8.8.5. Since the 3D Search unit consumes 300 to 600 Mbytes of memory, it takes time to back up data to external media if there are many 3D Search units in a scene group. You can unregister it before backing up data to save the capacity of the backup media and the backup time.

Name	Description		
Model Batch Reg.	■ 3D Search Model Batch Register		
	Model Registration Status of Search 3D Register Unregister Close		
	Start a dialog in which you can register and unregister models at		
	once.		
Register	Register all the 3D Search models in the currently selected scene		
	groups. If the number of 3D Search models in a scene group is N,		
	the processing time will be about 90 x N seconds.		
Unregister	Unregister all the 3D Search models in the currently selected		
	scene groups.		




Precautions for Correct Use

If you load a scene or scene group with unregistered 3D Search models, the models will not be registered automatically. If you perform measurement in this state, the 3D Search unit will be NG. Perform model registration for the 3D Search models in each individual scene, or click **Register** in the above dialog to register the models again.


8.4.2. Layout 2 Window

The main window of the Vision Sensor has buttons to launch user dialogs as shown in the figure below. This section describes buttons that are displayed in the Layout 2 window.



Dialog name	Description	
HandEye Calib.	Start a wizard for setting and executing hand-eye calibration	
Setting	(calibration between the camera and a robot). Details on configuring	
	settings using the wizard are described in 8.5.	
Pick Setting	Start a wizard for setting scenes for the picking application. Details	
	on configuring settings using the wizard are described in 8.6.	
Camera Calib. AOS	Start a wizard for setting and executing geometric correction for the	
Setting	3D Vision Sensor. For details on configuring the settings using the	
	wizard, refer to the Vision System FH Series AOS Camera	
	Calibration Operation Guide (Cat. No. Z451).	
Get	Refer to 8.4.1	
Robot Error	Refer to 8.4.1.	

The structure and functions of the wizard window are shown in the figure below.





Precautions for Correct Use

· When you click a processing item setting window, etc., the wizard may be hidden behind the main window. In this case, click the button that started the wizard again.

8.5. Hand-eye Calibration Configuration Using the Wizard

Configure the hand-eye calibration settings for the on-hand camera and execute a hand-eye calibration. Executing a hand-eye calibration allows you to establish the positional relationship between the camera coordinate system of the 3D Vision Sensor and the flange coordinate system of the robot and then convert the position of the workpiece detected by the 3D Vision Sensor into the position in the robot coordinate system. Hand-eye calibration parameters can be referenced by the Container Detection or Grasp Planning processing item.

The description here assumes that the Layout 2 window is displayed.

MARNING

- Make sure that you always use a sensor controller project that matches the robot type. If the type is mismatched, the robot may operate in an unexpected manner.
- Make sure that the robot is operated by personnel who have completed special training for safety and health.
- Make sure that you can stop the operation of the robot at any time by pressing the emergency stop button.





Precautions for Correct Use


- For robot-related settings, refer to the *Vision System FH/FHV series Robot Connection Guide* corresponding to each robot in *Related Manuals*.
- This wizard configures only the minimum required settings. To configure advanced settings, refer to the relevant topics in 8.7, or the following document listed in Related Manuals in this manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)




Note

• If the wizard does not work as described, you may have skipped some step in the middle of the procedure. In this case, redo from the beginning of the wizard.

Before proceeding to the following step, please check the network connection to the robot as described in section 3 of the *Vision System FH/FHV series Robot Connection Guide* corresponding to each robot in *Related Manuals* for the robot to be connected.





If 3D Search or calibration fails, refer to *Key Points for Measurement and Adjustment* in the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445).

8.6. Hand-eye Camera Pick Application Configuration Using the Wizard

Configure the application to pick workpieces with the hand-eye camera. Specifically, register the target workpiece model, hand, and container, and then perform a 3D Search, detect the grasped workpiece, and output the command position to grasp workpieces to the robot controller.

Before you start the following setting procedure, complete the settings described in 8.5. The description here assumes that the Layout 2 window is displayed.

MARNING

- Make sure that you always use a sensor controller project that matches the robot type. If the type is mismatched, the robot may operate in an unexpected manner.
- Make sure that the robot is operated by personnel who have completed special training for safety and health.
- Make sure that you can stop the operation of the robot at any time by pressing the emergency stop button.





Precautions for Correct Use

- For robot-related settings, refer to the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals*.
- This wizard configures only the minimum required settings. To configure advanced settings, refer to the relevant topics in 8.8, or the following document listed in *Related Manuals* in this manual. *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445)



Note

• If the wizard does not work as described, you may have skipped some step in the middle of the procedure. In this case, redo from the beginning of the wizard.

Step	Description	Window image, diagram
1	In the main window of the Vision	HandEye Calib. Setting Robot Error
	Sensor, click the Pick Setting button to start the wizard.	Pick Setting


According to the wizard instructions, configure the settings on pages 1/35 to 24/35 of the wizard. To configure the settings on the next page, click the **Next** button. To return to the settings on the previous page, click the **Previous** button.


To close the wizard, click the **Close** button.


In 7/35 [Move to Imaging Position], Set the imaging position so that the distance to the imaging target is 400to 600mm.

In 11/35 [Register Floor Surface], the floor area can be registered by dividing it into several area. Register the area on the same plane and do not include surfaces that differ in height or inclination.

For details on how to register the hand data and grasp point in the 3D Data Manager window from pages 25/35 and 26/35 of the wizard, refer to 8.8.6 in this manual.







For troubleshooting for each processing item in the picking application, refer to Key Points for Test Measurement and Adjustment for each processing item in the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445).

For how to operate the robot to pick a workpiece based on the settings in this manual, refer to section 6 of the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals* in this manual.

8.7. Hand-eye Calibration

This section describes hand-eye calibration settings and procedure.

Calibration parameters describes geometrical relation between camera optical center and robot flange center. This allows you to convert the position of the workpiece detected by the 3D Vision Sensor into the position in the robot coordinate system.

The calibration parameters are referenced from Container Detection unit and Grasp Planning unit.

The description here assumes that the Layout 0 window is displayed.

△WARNING

- When hand-eye calibration executing the robot moves variety of positions and postures, but it does not consider surrounding obstacles. Please remove obstacles around robot in case of collision.
- During calibration, the move command values to the robot are output in the base coordinate system of the robot. Set the robot to the base coordinate system before calibration.





Precautions for Correct Use

- Do not change the default values of system variables and scene variables. If you change them, the robot will not operate correctly.
- For robot-related settings, refer to the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals*. It is also referred to as Robot Connection Guide in this manual.

Use the following work flow to configure the settings.

8.7.1	Robot Connection	Start the setup program on the robot side and confirm that the Vision Sensor can communicate with the robot.
	▼	
8.7.2	Camera Image Input AOS Setting	Set shutter speed, gain and depth range to the calibration target be measured properly.
	▼	
8.7.3	Robot Type Setting	Set robot type to be connected to the Vision sensor.
	_	

8.7.4 3D S	earch Setting	Generate 3D search model from calibration target CAD file and set/adjust 3D search parameters.
8.7.5		Set robot move range parameters which
Hand	I-eye Calibration Start Position	enable capture of the calibration target in
Regis	stration	many points and postures.
	▼	
8.7.6		Set robot move range parameters which
Hand	I-eye Calibration Setting	enable capture of the calibration target in
		many points (sampling point) and postures.
	▼	
8.7.7 Hand	I-Eye Calibration Execution	Execute hand-eye calibration and calculate
		the calibration parameters.

8.7.1. Robot Connection

During hand-eye calibration, the Vision Sensor communicates with the robot to perform robot operation. Before proceeding to the following step, please check the network connection to the robot as described in section 3 of the Vision System FH/FHV series Robot Connection Guide corresponding to each robot in Related Manuals for the robot to be connected.

Step	Description		Window image, diagram
1	Click Scene switch button on the main Window of the Vision Sensor.	ms Robot Error	Edit flow Data save Scene switch Layout0 Switch layout Robot Current Pos. Get Robot Command Pos.
		FH Macro Ver.	X: 208.4308 W: -174.3759 X: 0.0000 W: 0.0000 Y: -573.9842 P: 1.3117 Y: 0.0000 P: 0.0000 Z: 358.3550 R: 90.2261 Z: 0.0000 R: 0.0000
	Select the No.125 scene that contains the hand-eye calibration scene.	Switch scene Scene group : Scene :	0.Scene group 0 Switch 125.Handeye_Calibration_Pick_Onhand_6axis_
	Click OK to switch scene.		OK Cancel
2	Start the robot setup program a ccording to the procedure described in section 5 of the <i>Robot Connection Guide</i> .		

MARNING


Running the robot program causes robot arm motion.

Operate the robot in the state whereby pressing the [Emergency stop]



3 Click the **Get** button. Confirm that the current position of the robot is displayed correctly.

button can stop its motion anytime.




In the main window, click the Robot Operation button. Then, in the Robot Operation dialog displayed, click the Edit button and set the operation speed of the robot. The operation speed of the robot depends on the robot model.




Place the calibration target object in the center of the field of view as shown on the figure on the right.

At this time, with the hand-eye calibration target set in the center of the field of view, secure a hemispherical trajectory with a radius of about 450 mm for the robot.



Adjust the position of the robot so that the hand-eye calibration target to capture is near the center of the field of view.
Click the Robot Operation button in the main window and use the Jog Operation buttons to operate the robot. You may use the robot pendant to perform jog operation.






MARNING

- · Running the robot program causes robot arm motion.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



8.7.2. Camera Image Input AOS Setting


Set the imaging position, shutter speed, gain, and measurement range so that the hand-eye calibration target can be measured properly.





If the exposure is appropriate, the distance image of the hand-eye calibration target as shown in the figure on the right will be displayed.

If you see only black in the image window, check the box for "Captured image" in the "Display setting" at the bottom right of the screen and confirm whether or not you can observe the projected mesh image on the target object. Set the camera settings so that the projector pattern has high contrast, as shown in the figure on the right.

Also confirm whether of the target object form the 3D Vision sensor is in the range of "measurement range of Z".









8.7.3. Robot Type Setting


Follow the procedures below to set the robot type and robot coordinate system which connect to the Vision sensor.



8.7.4. 3D Search Setting

Follow the steps below to configure and adjust the 3D Search settings for the calibration target.






Open "Judge cond." tab to set the judgement condition.

Set the lower threshold for "Contour correlation" to be lower than that for "Surface correlation". Normally, there is no need to change the default value.

Click **OK** to complete settings




7 Click the Measure button of the Main Window and confirm 3D Search succeeded to detect the calibration target.




Open the 3D Search processing item and check that the hand-eye calibration target is detected.

Click the **Draw with 3D** button at the lower right of the Measurement tab of the 3D Search processing item. You can now check that the points measured with the 3D Visualizer correctly match the CAD data for hand-eye calibration.


If the target is not detected, adjust the candidate level settings in the Measurement tab.





8.7.5. Hand-eye Calibration Start Position Registration


Follow the steps below to register the start pose of hand-eye calibration. Calibration will start from the position that you register here, and the robot will stop at this position after the calibration is completed. Perform the procedure described in 8.7.1 when the robot is running.



8.7.6. Hand-eye Calibration Setting

Set the conditions of the 3D vision camera installed on the robot and the movement range of the robot during hand-eye calibration, which are required to execute hand-eye calibration. Follow the steps below to set and execute hand-eye calibration.

To set hand-eye calibration, you need to get the position and posture of the robot according to the procedure described in 0.



3 Set the offset position (X,Y,Z) of the 3D vision camera's camera coordinate origin in flange coordinate system from the robot flange center.


The directions of Position X, Position Y, and Position Z are determined by the direction of the robot flange on which you install the 3D Vision Sensor. Check the direction of the flange coordinate system of the robot before you set them.

This positioning need not be so precise (±5mm tolerance).

In **Camera Y-axis minus**, set the direction in which the 3D vision camera is mounted.

Select Robot flange axis that same direction to the 3D camera's Y axis minus direction.

Specific examples are given in Supplementary Information on Camera Installation Settings 1 at the end of this section.



X-axis minus direction


Y-axis plus direction

Custom

In the example figure shown on the right, the -Y axis (Y-axis minus direction) of the camera coordinate system coincides with the -Y axis of the flange coordinate system.


For the direction, an error of ±5 degrees is allowed.

To set a different angle intentionally, select **Custom** and set the angle. For how to set an angle, refer to *Supplementary Information on Camera Installation Settings* 2 at the end of this section.




4 Open "Target settings" tab to set the calibration target pose and posture which are search result of the "3D Search" unit result.

If you load a sensor controller project corresponding to the robot type, there is no need to enter or change the settings because the system variables (SY.XXX) are already set.




Open "Sampling settings" tab to set Calibration start point.
Confirm the "Calib. Start pose" values (System variables) are same position and posture which registered section 8.7.5.
If you load a sensor controller project corresponding to the robot type, there is no need to set or change the settings because the scene variables (SC.XXX) is already set.



During the Hand-eye calibration procedure the robot moves half sphere trajectory from "Calib. Start pose" with keeping the calibration target in center of the 3D camera view.

The camera measures the calibration target from many directions and calculate camera location from the robot flange center.

For the working range of the robot based on each parameter, refer to Supplementary Information on Sampling Settings at the end of this section.



Set distance from 3D vision camera to the handeye calibration target in "Ref radius"

Set a Working range (radius transfer range) and Divisions (transfer step num >=2) to the "Direction Radius".


Set polar direction inner angle of the flange trajectory and transfer step num to "Direction Polar (Polar coord)". Division must be greater or equal 2.


Set Azimuth direction inner angle of the flange trajectory and transfer step num to "Direction Azimuthal (Polar coord)". Division must be greater or equal 2.

Polar and Azimuth angle is applied to plus and minus side.

Set Perturbation angle 2-5.0 degree. Too much perturbation angle cause loss of the calibration target object from 3D camera view.

Normally, there is no need to change the default values. If the values are too large, the calibration target will be out of the field of view.





Sampling points are generated and shown on "Robot move pose list for sampling" as shown on the figure in right.

The number of sampling points is product of transfer step (Divisions) of "Direction radius", "Direction Polar" and "Direction Azimuthal". The hand-eye calibration target will be captured at the position specified by these coordinates.

The figure on the right shows an image of the imaging position seen from directly above and from the side of the robot in accordance with the robot move pose list for sampling.

If you find any abnormal value as a coordinate of the robot, review the settings in the Target settings and Sampling settings tabs.


An abnormal value refers to a position that the robot cannot reach, or a position where it is obvious that a collision will occur. However, it depends on the model and orientation of the robot.

Check the working range of your robot.

This completes the setting for hand-eye calibration.

Click the **OK** button to close the setting window.

No.	Robot position X	Robot position Y	Robot position Z	Robot po ^
0.	346.5722	8.4900	517.5165	165.0
1.	277.3218	176.3017	447.6972	175.0
2.	329.1021	190.9072	457.6612	166.
3.	376.5276	198.5674	459.1024	162.0
4.	415.0559	186.6293	461.2183	160.9
5.	321.1734	69.0463	484.8544	169.
6.	343.4995	73.4434	491.3585	164.
7.	359.6419	80.4628	491.0244	162.
8.	367.9586	75.8907	488.8067	165.0
9.	320.0393	-43.2057	488.3442	168.
10.	342.2670	-48.5481	495.0461	163.:
11.	358.4083	-41.6427	496.3634	161.8
12.	366.8143	-37.3737	493.7674	164.
13.	274.0189	-150.6192	458.2058	173.0
14.	325.4835	-167.2609	468.5800	163.9
15.	372.8808	-162.3964	474.8862	159.
16.	411.6464	-150.8415	476.0602	158.:
17.	417.3168	-172.5913	517.2759	158.0
18.	374.6609	-185.0599	515.9606	158.
19.	323.3915	-175.4746	511.9479	164.:
20.	268.0492	-158.4928	501.1636	173.:
21.	368.6923	-49.3882	539.0639	163.
22.	358.9636	-54.1755	541.5837	161.!
23.	341.6057	-46.5029	539.2022	163.
24.	318.0596	-41.2660	532.3936	169.:
25.	369.9371	73.8222	535.6197	164.
26.	360.3050	78.6031	537.9111	162.4
27.	342.9396	85.5324	533.8782	164.4
28.	319.2883	80.3450	527.4785	170.
29.	421.0224	194.1880	507.1662	160.0
30.	378.6254	207.3486	505.1718	161.
31. <	327.3090	212.2825	496.2941	167. *



MARNING

- The scene loaded by configuration copy in section 7.2 has predefined scene variables and system variables. You may not edit these variables manually (with TDM or setting windows).
 These variables are set automatically by the operations of the dialogs described in this section.
- Proceeding with the subsequent steps without setting [Reg. Calib. Start Pos] (Calibration start position) can cause unexpected robot motion. Do not forget setting the calibration start position.






Precautions for Correct Use


 If you click the Measure button in the main window after configuring the hand-eye calibration settings, be sure to execute Clear measurement from the Function menu in the main window before you execute handeye calibration.

To perform hand-eye calibration, click the **HandEye Calib.** button in the main window.

■Supplementary Information on Camera Installation Settings 1:

The **Position X**, **Position Y**, **Position Z**, and **Camera Y-axis minus** settings in **Camera mount settings** differ depending on the orientation of the robot flange in which the 3D vision camera is installed. The following shows examples of setting different flange conditions when the positional relationship between the center of the flange and the 3D Vision Sensor is as shown in the figure below.






■Supplementary Information on Camera Installation Settings 2:


When you install the 3D Vision Sensor at a tilt relative to the flange coordinate system, select **Custom** and enter the pose of the 3D Vision Sensor in the Euler angle representation. As the representation of pose in Euler angle, you can select ZYX, ZYZ, or XYZ. If you are not familiar with the representation of pose, it makes easy to set the ZYX representation.

When **Representation of pose** is *ZYX*, with the flange coordinate system and the camera coordinate system set in the same orientation, rotate the Z axis, Y axis, and X axis of the camera coordinate system in this order to set the pose of the 3D Vision Sensor in an installed state.

The following explains the ZYX representation of pose with examples, where the camera is installed at a tilt relative to the robot flange Z axis. In this manual, coordinates are right-handed, and the direction of rotation is right-handed screw.



	Example 1	Example 2	
Z axis rotation	Yf Yc Xc Zc	Xf Yf Yc Zf Xc Zc	
	Z axis rotation=0deg	Z axis rotation=-90deg	
Y axis rotation	Yf Yc Yc Xc Zc	Xf Yf Yc Xc Zc	
	Y axis rotation=0deg	Y axis rotation=0deg	




Note: For convenience of explanation, the positions of the flange and 3D Vision Sensor are drawn apart.

■Supplementary Information on Sampling Settings:

The following shows sampling setting parameters with an image of the working range of the robot.


For details on each parameter, refer to the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445).






The angle range in which the hand-eye calibration target is seen with the Calib. start pose as the starting point. If Working range is 40 deg and the number of divisions is 4, the target will be captured at angles obtained by dividing the angle range from -20 to +20 deg by 4.

If Working range is too large, the robot may collide with the camera or move out of its movement range, which makes it impossible to capture the target. Be sure to set a safe range.




[Direction Polar (Polar coord)]




The angle range centered on the hand-eye calibration target. The set range will be symmetrical when seen from the robot.

If Working range is 40 deg and the number of divisions is 4, the target will be captured at angles obtained by dividing the angle range from -20 to +20 deg by 4.


If Working range is too large, the robot may collide with the camera or move out of its movement range, which makes it impossible to capture the target. Set the angle in a safe range depending on the robot and environment.



[Direction Azimuthal (Polar coord)]




Set the angles at which the imaging direction of the 3D Vision Sensor is shifted from the imaging position determined by radial, polar angular, and azimuthal movements. Setting these angles is effective to stabilize the calculation for hand-eye calibration. If the values are too large, target for hand-eye calibration may be out of the field of view. Normally, there is no need to change the default settings.



[Perturbation (Sphere center cord)]

8.7.7. Hand-Eye Calibration Execution

Execute hand-eye calibration based on the settings described in the previous sections. Make sure that the warmup of the 3D Vision Sensor is completed before you execute handeye calibration.



The progress of the hand-eye calibration is indicated as *Number* of executed steps/Total number of steps in **Step** in the detailed result display window.

When the hand-eye calibration is completed, (Completed) will appear next to **Step**.



△WARNING

- Clicking [Auto Exec(Robot Move)]or [Step Exec.(Robot Move)] drives the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



△Caution

- Make sure that an appropriate robot speed is set according to the procedure described in 8.7.1 before you execute calibration.
- Make sure to confirm the robot movement by actually observing it instead of relying on the camera image.
- If you click the AUTO Exec. or STEP Exec. button when the warmup of the 3D Vision Sensor is not completed, the measurement will be NG and the hand-eye calibration will not complete. Try again after the warmup is completed.




When Hand-eye calibration is complete, the robot moves back to the calibration start point.

Click the "Hand-Eye Calibration" processing item icon and then open its "Calibration result" tab.

The results for Positions X, Y, Z and Posture RX, RY, RZ indicate the offset between the optical origin of the camera coordinate system and the origin of the flange coordinate system obtained as a result of hand-eye calibration.

If they do not deviate significantly (a few centimeters or more, or 5 degrees or more) from the settings in the Instruments settings tab, and the error evaluation values are less than 1.0, the calibration will be completed.






The origin of the actual camera coordinate system is located inside at about a few more than 10 mm from the surface of the 3D vision camera. Therefore, the indicated result for Position Z will be 10 and a few mm smaller than the setting.

If there is a large error, change the value of the setting in the Sampling settings tab and execute hand-eye calibration again.


The calculation of the hand-eye calibration is now completed. Click the **OK** button to close the setting window.





Precautions for Correct Use

- If the calibration results show an error evaluation value of 1.0 mm or 1.0 deg or larger, the sampled data may contain undesirable values (measurement errors, robot movement errors, etc.), or the sampling points may not be appropriate. The errors may become larger when the position and posture in the camera coordinate system detected by the 3D Vision Sensor is converted into those in the robot coordinate system.
- For how to adjust the settings when the calibration results show an error evaluation value of 1.0 mm or 1.0 deg or larger, refer to *Key Points for Measurement and Adjustment* in *Hand-eye Calibration processing item* in the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445).



8.7.8. Troubleshooting for Hand-eye Calibration

If 3D Search or calibration fails, refer to *Key Points for Measurement and Adjustment* in the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445).

8.8. Pick Application Flow for the Hand-Eye Camera System

This section describes sample flow building procedure for Pick & Place application.

The procedure consists of 3D camera setting, Container and floor registration, Search model registration and 3D Search setting, Hand and Grasp point registration, Grasp plan setting and Output destination position and posture to the robot.

Before proceeding with the steps in this section, please complete the settings described in section 8.7.

The description here assumes that the Layout 0 window is displayed.



Precautions for Correct Use

- The Pose and posture output of Grasp Planning unit in section 8.8.7 is expressed in the robot base coordinate. Please set the robot to the robot base coordinate system.
- Do not change the default values of system variables and scene variables. If you change them, the robot will not operate correctly.
- · For robot-related settings, refer to the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals*. In this manual, it is referred to as *Robot Connection Guide*.

Use the following work flow to configure the settings.

8.8.1	Preparation	Configure the settings to prevent output to the robot and switch to the scene to configure.
	▼	
8.8.2	Robot Connection	Execute the setup program on the robot controller for getting position and posture of the robot.
	▼	
8.8.3	3D Camera Image Input AOS	Set and adjust the Camera Image input AOS unit so that the target object is measured properly.
	▼	
8.8.4	Container Detection	Register the floor on which the container is placed and set the size of container and the container search condition. The registered floor data is used to locate the container and is used for collision detection by the Grasp Planning unit. The

_	
	result of Container Detection is used as a
	mask data for 3D Search unit.
O O C OD Oceans for Application	One and a OD and the second
8.8.5 3D Search for Application	Generate 3D search model from the search
_	target object (workpiece) CAD file and
_	set/adjust 3D search parameters.
8.8.6 Making Hand (Vacuum Gripper)	Model the hand (end effector) by combining
Model and Grasp Point Registration	cubes and cylindrical columns.
Wodor and Crasp Fount Registration	·
	Register the grasp point of the workpiece.
8.8.7 Grasp Planning	Setting for ordering the 3D Search result by
	grasp condition.
▼	
8.8.8 Result Output	Output the grasp candidate location to the
	robot.
8.8.9 Saving the Settings	Save the scene data.
o.o.o	Save the sectic data.

8.8.1. Preparation

Switch to the scene to configure.

Loading a sensor controller project sets the scene named "Pick on hand_6 axis" for Scene No. 0 as a sample scene for the picking application.




Precautions for Correct Use

• When you create a new scene for picking, be sure to copy the "Pick_Onhand_6axes" of Scene No as a template. 0. And use the scene maintenance copy function to copy the scene. The application will not operate normally if you combine individual processing items. The sample scene is configured with system variables and scene variables that are required to construct an application.

Step	Description	Window image, diagram
1	On the main screen of the vision sensor, uncheck the Output checkbox to avoid unexpected robot motion while doing the setting procedures	Camera image meas. Measure Output Continuous meas. 1st. NG unit Next NG unit O.Camera Image Input AOS
2	Switch to the scene for picking. The scene "0.Pick_Onhand_6axis" that you copied by using the scene maintenance copy function.	Switch scene Scene group: [0.Scene group 0 Switch Scene: [0.Pick_Onhand_6axis] OK Cancel


8.8.2. Robot Connection

Check the network connection between the Vision Sensor and the robot, and move the robot to the imaging position.



Operate the robot to the measurement position.
Set the distance between the target workpiece and the 3D
Vision Sensor in the Z direction to 400 to 600 mm.

Click the **Robot Operation** button in the main window and use the **Jog Operation** buttons to operate the robot. You may use the robot pendant to perform jog operation. Here, move to an approximate position and finely adjust it later while checking the field of view.




8.8.3. 3D Camera Image Input AOS

Follow the procedures below to set shutter speed, gain and depth range so that the target object be measured properly.

For details on each parameter of the Camera Image Input AOS processing item, refer to Camera Image Input AOS in the following manual.

Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)



Set an appropriate "Measurement range of Z" between 400-600mm.


"Measurement range of Z" is the distance from the 3D camera to target object.


The camera Through image will be displayed by clicking the **Change display** button.


Adjust shutter speed, camera gain and Light gain so that the 3D depth image be captured properly.

When adjusted properly, you will see the target object 3D depth image similar to that shown in the figure on the right.

Black color denotes unmeasura ble or out of range area.








If you see only a black image in the window, check the box for "Captured Image" in the "Display setting" at the bottom right of the screen and confirm whether you can observe the projected mesh pattern image on the target object.

After you configure the camera settings, click the **Change display** button again to freeze the image display.



Open the Camera setting (3D) tab for 2D image capture setting.

The camera Through image will be displayed by clicking the **Change display** button.

Adjust shutter speed, camera gain and Light gain so that the 3D depth image be captured properly.


As with the settings for processing item such as Shape Search III that uses the edges of images, set the conditions to achieve good contrast of the target workpiece and container.


After you configure the camera settings, click the **Change display** button again to freeze the image display.

Click **OK** to complete setting and

close the setting screen.











Precautions for Correct Use

 Setting different shutter speeds in the Camera setting (3D) and Camera setting (2D) tabs results in an overhead of about 50 ms in the imaging time. Set the same value as much as possible. If you cannot set the same value, adjust the shutter speeds by the camera gain and light gain.

Increasing the camera gain in Camera setting (3D) tab does not have significant effect on the detection accuracy of 3D Search.

8.8.4. Container Detection

Follow the procedures below to register the floor where the container is placed and set the size of container and container search condition. The registered floor data is used to locate the container and used for collision detection by the Grasp Planning unit. The Container Detection unit uses 2D image, so change Camera Image Input AOS setting enables to capture 2D image.

Detectable containers are limited to those listed in 3.3. There is also a limitation in size that they must fit entirely in the field of view of the 3D vision camera.

Registering and detecting a container allows for container detection between the container and the hand (8.8.7).

For details on each parameter of the Container Detection processing item, refer to Container Detection in the following manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)

Step	Description	Window image, diagram
1	Operate robot to the measurement position. Make sure the floor is clear (no container, no workpiece).	
	Click the "0.Camera Image Input AOS" icon on the Main window of the Vision Sensor to open the setting screen.	1.Container Detection 2.3D Search 3.Grasp Planning 4.Calculation 5.Result output (Message)

Open "Camera Setting 3D" tab and click **Display Change.**

Then Confirm that the floor is measured correctly.

If the depth image is not captured stably due to glossy or uneven surface, place a piece of thin, white paper on the floor. Prescrinage display

Change signiny


Change signiny

Change signiny

Change signiny

Displaying the signing to some signing to


After confirming the above, place the container on the floor.



Open "Camera Setting 2D" tab

Confirm that the container is in appropriate imaging conditions (detectable by Shape Search III) with the condition settings in the Camera setting (2D) tab in 8.8.3.

By doing the above, 3D setting for the floor measurement and 2D setting for the container measurement are completed. Click [OK] to close the setting screen.





Precautions for Correct Use

- If the container position is fixed and the condition settings in 8.8.3 are inappropriate for detection, once adjust the imaging condition settings to achieve appropriate conditions for container detection and then perform container detection. After completion of the container, return to the condition settings in 8.8.3.
- If you need to detect the container position every time, return to the Camera setting (2D) tab in 8.8.3 and configure the condition settings so that both the workpiece and the container can be appropriately measured.
- 2 If you have adjusted the robot position after the connection check with the robot in 0, click the **Get** button in the main window to reacquire the current position of the robot.




Make sure the floor is clear (no container, no workpieces) and click [Measure] to measure the floor plane without the container.







4 Click the "1.Container Detection" icon on the Main windows of the Vision Sensor to open setting screen.



Open "Input parameters" tab and confirm that the Input settings are as shown in the right figure.
Usually no change from the initial settings is needed.



Open "Coordinate settings" tab.
Confirm that the processing unit set in section 8.7 "Hand-Eye
Calibration Execution" is present.




Confirm that "Flange coord. seen from robot base coord" values are same as the robot current position.

The robot current position repre sents the position that you obtained by pressing the **Get** button in the main window.

Open the "Floor Settings" tab and then Click the **Edit** button to specify the floor region for measurement.

The position of the container is based on the floor set here.

Register only the floor on which the container will be placed.



You can also register the region by dividing it into up to four multiple areas. Register area that are on the same plane.

Do not include surfaces with different heights or gradients. If the registered areas are too small, the registration will fail, or error will be large.


If the area is small in one area, set up four arbitrary area on the same plane.


Click **OK** to finish floor region setting.

Click the **Measure** button and register the floor on which the container will be placed.

The information on the detected floor surface will be displayed in **Floor detection result**.

Confirm that the value of **Position Z [mm]** does not deviate
significantly from the distance
between the 3D Vision Sensor
and the floor surface.






Checking **Display floor figure** in **Display settings** displays 100 by 100 dots in the pane.


The color of the dots indicates the distance from the camera, which is the same as the distance image display in the Camera Image Input AOS processing item.

The diameter of points with a smaller error in the measured value than the value of the registered plane will be displayed larger. Confirm that points with large diameters are distributed over the entire measurement region that you set.

If the points with large diameters are biased to either side or in parts of the measurement region, check



Example of an unevenly distributed image



△Caution

If you have changed the height or gradient of the floor surface on which the container is placed, the imaging position, or the position or posture of the robot after you clicked the **Measure** button in the Floor setting tab, redo the floor registration from Step 2 (reacquisition of the current position of the robot) of this procedure. Otherwise, the robot hand may collide with the floor.





Place the container on the floor of measurement position.

Click **Measure** button on the Main Window and capture a 2D image of the container.

The container is registered at the imaging position. If you have corrected the position, click the **Measure** button and capture the image again.

Click "1,Container Detection" icon again and open setting screen again.







8 Open "Shape settings" tab to set size of the container.

You can register only the supported containers shown in 3.3.

The width is the horizontal direction of the camera image (X axis), and the depth is the vertical direction of the camera image (Y axis).






After you enter the shape parameters, green lines that represent the rims of the container seen from directly above are displayed in the center of the pane.

Check that there is no deviation in size.


Note that the position of the lines appears to be misaligned with the container image because the container is not detected yet.



Open "Region settings" tab and click **Edit** to set search region of the container.

Specify the container search region.

Click the **OK** button to complete region setting.



Open "Measurement" tab and detect the container by setting above.

Confirm that the box for [Measure once] is checked.

Click the **Measure** button once. The container will be displayed with a green frame as shown in the figure on the right indicating that container detection was successful.


If the detection failed, click the Advanced button and adjust edge level. The container will be detected based on the edges of the 2D image.


Clicking the **Draw with 3D** button displays the set container in wireframe with the measurement results overlaid on it.
Click the **End** button to close the 3D Visualizer window.

Click the **OK** button to close the container detection settings.

The container detection procedure stores the shape and position of the container in the robot base coordinate system.

If you have changed the position of the container, redo the procedure from Step 7 (measurement of the container image).





△ Caution

• If you uncheck Measure once in the Measurement tab to measure the position of the container in every measurement, set the container position so that it is not out of the region that you set in the Region settings tab. In addition, make sure that the container can be detected with the workpiece actually contained in the container.




8.8.5. 3D Search for Application

Configuring the 3D Search settings consists of loading the CAD data for the search target model, registering the model, and setting search parameters. You can use the setting procedure below to get the 3D position and posture of the search-target workpiece (in the camera coordinate system) from the measurement results of the 3D Vision Sensor. For details on each parameter of the 3D Search processing item, refer to 3D Search in the following manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)



Precautions for Correct Use

You can load CAD data in the STL format. For details, refer to 3D Data Manager in the following manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)



2 Insert USB flash drive which stores the target object CAD file into USB port.

Click the "1. 3D Data Manager" icon on the Main window of the Vision Sensor to open the setting screen.

Open the "CAD Data" tab.

Select a number in the list that is not registered.

Click the **Import** button on the bottom left to open File Explorer.


Select the target object CAD file in the USB flash drive and then click the **OK** button to load the file.


The loaded CAD data will be displayed as shown in the figure on the right.

You can use the slider at the bottom right of the window to rotate the loaded CAD data.


Confirm the target object is correct. Then click the **OK** button to close the setting screen.


At this point the target object CAD data loading is completed.













Precautions for Correct Use

If the size of the CAD data is too large, the display may become very slow. If the display is slow, adjust the granularity of the CAD data output from the CAD software.

Click **Scene switch** button on the main Window of the Vision Sensor.

Select the sample scene (scene No.0) and Click **OK** button to switch scene.




4 Put the target workpiece in the container and set the registered container in place.



In the main window, click the

Measure button to capture an
image according to the camera
condition settings in 8.8.3.

Although the measurement result
will be NG since the settings are
not yet complete, proceed to the
next step.



6 Click the "2. 3D Search" icon on the Main windows of the Vision Sensor to open its setting screen.



Open the "Input parameter" tab and confirm that Input settings are as shown in the figure on the right. Usually there is no need to change from the initial settings.




7 Open the "Model" tab to select the target object file.

In "3D data settings", set the "Reference data" to the target object loaded to 3D Data Manager in STEP 2.

Set the distance range from the 3D camera (camera coordinate system) in which the target objects will be placed.

The narrower the range, the shorter the detection time.

If the shape of the model is symmetrical from front to back (i.e., identical even when it is rotated 180 degrees around the X or Y axis from the state displayed in the window) as shown in the figure on the right, adjust the reference posture RX, RY, and RZ values to achieve front to back symmetry and check the Having front and back symmetry about current view check box. This will reduce the size of the 3D Search model and speed up the processing time.



If the model is not symmetrical from front to back, set it to an orientation that secures the largest area in the setting window, or a workpiece posture that frequently appears on the captured image of the actual package.

Click the **Register** button to register the CAD data. This process generates 3D Search model data. "Under registration" message blinks during the registration process. When completed, the label will change to [Unregister].

The registration takes about 90 seconds.







Precautions for Correct Use

- Changing the posture in **Display settings** at the lower right of the window does not affect the **Reference posture** settings in the advanced settings. To change the **Reference posture** settings, click the **Advanced** button.
- 8 Open the "Region settings" tab to Set the region so that the measurement FOV covers the container.

Click the **Edit** button to set the measurement region.

When using result of container detection as a mask, place a check on **Enable masking** and set the container detection unit to Unit ref number of Masking settings.





If the container detection is successful, a mask region will appear in the window. If the mask region is colored "black" as shown in the figure on the right, the black region will be excluded from the target of measurement.

Adoption and the second of the

Measurement

Judge cond.

Region settings

9 Open "Measurement" tab to set measurement condition of 3D search.


Open "Measurement" tab to set measurement condition of 3D search.


In 3D Search, candidates will be selected at the following two candidate levels.

Candidate Lv.(surface): The match level for curved surfaces between CAD data and measurement result.

Candidate Lv.(contour): The match level for contours between CAD and measurement results. There is an "OR" relationship between the two candidate levels. Candidates beyond one of the candidate levels will be included in search results.

Select "Sort kind" for sort order of searched results






When you want to limit searched candidate posture or distance (from camera), adjust the ranges of Latitude, Longitude, Roll and/or Distance. Click **Return** button to close advanced setting.

Click the **Draw with 3D** button at the bottom right of the window to start the 3DVisualizer. The searched CAD data will be overlaid on the 3D data. You can check the search results on the 3D display.


After you check the results, click the **End** button to close the window.



- 10 If the workpiece cannot be detected with the default parameters, adjust or change any of the following three settings.
 - ■Adjusting the candidate level settings

Decrease the Candidate Lv. (surface) and Candidate Lv. (contour) values from the default value of 60 to about 40.

If the search results are displayed, check the surface correlation and contour correlation values and adjust the candidate level settings to a slightly lower value than the detected correlation value.




Candidate Lv. (Surface) < Surface correlation Candidate Lv. (contour) < Contour correlation ■Changing the edge information to use


Check **Display contour feature** in **Display settings** to display the contour features.

Click the **Advanced** button to open the advanced setting window.

In Edge info used, switch the setting between Depth and Image to compare the contour features. Select the setting with clearer contours and less noise.

■Adjusting the edge level
If the contours are unclear or
there is too much noise when the
contour features are displayed,
uncheck **Auto** for the edge level
setting. Adjust the edge level to
make the edges clearer with less
noise.








11 Open "Judge Cond" tab to set judge condition.

If judge by position and posture (in camera coordinate) needed, Click [Advanced] button and set range.


Click **Return** button to close advanced setting.

Click **OK** to complete 3D search settings and close the setting window.




12 In the main window, click the

Measure button and confirm that
the 3D Search results are
displayed.



8.8.6. Making Hand (Vacuum Gripper) Model and Grasp Point Registration

Create and register the shape of the hand (gripper) used to grasp workpieces. To create a hand shape, combine cylinders and cubes. You can create one-point vacuum and two-finger parallel open-close hands. You can also register a camera as part of the hand to detect a collision with the container.







Precautions for Correct Use

You cannot register hand shapes directly from CAD data.

Prepare a drawing that describes the dimensions of each element of the hand.


This section explains how to register the hand by using example shown in below figure. This section describes the model registration procedure for a single-point vacuum hand (including the 3D Vision Sensor) as shown in the figure below. For the procedure for a two-finger hand, refer to 9.1 Making Hand (Tow finger Gripper) and Grasp Point Registration.





■Hand coordinate

Hand data uses the robot flange coordinate system. Check the orientation of the robot flange coordinate system when you install the gripper.



■Components of the hand


Example of a vacuum hand consist of following element.

Part	Description
Pad	Vacuum pad that makes contact with the target object.
Bellows	Expanding and contracting part of vacuum pad.
Base	All element other than Pad and Bellows. Jigs to connect the robot's
	flange, pipe, camera and other element moves with the hand.

■Location and dimensions of components


Position and posture of elements are described in the flange coordinate. The position of the element is center of roof plane or cross section of diagonal line. Height/ Width Z is minus Z direction in flange coordinate system.

The root of the hand is located at the origin of the flange coordinate system. Create the tip of the gripper in the Z-axis plus direction of the flange coordinate system.



■Accuracy of the hand

Accurately set the position and dimensions of the tip that makes contact with workpieces (shown in a red outline in the figure below). In particular, set the dimensions in the Z-axis direction of the flange coordinate system correctly. For other elements, you can use approximate shapes such as circumscribed cubes and cylinders without problems.






Precautions for Correct Use


- Output of the Vision Sensor is calculated based on the hand shape specified here. Position and size of the element which contact to the target object must be set precisely.
- Register the elements attached to the hand (camera, connectors, jigs attached to the hand, etc.) that require collision judgement with the container together with the hand.

Follow the steps below to register the hand data, and then register the grasp point. For details on each parameter of the processing item, refer to 3D Data Manager in the following manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)

Step	Description	Window image, diagram
1	Click Scene switch button on the main window to switch to Scene No. "126. 3D Data Manager". Click the "1. 3D Data Manager" icon on the Main windows of the Vision Sensor to open its setting screen.	0.Camera Image Input AOS 1.3D Data Manager




Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (Bellows).



If there is no bellows element, set the difference in length betw een the non-adsorbed state and the adsorbed state of the pad (deformation of the tip).

The length of the Bellows changes when vacuum pressure is applied so open the [Whole hands] tab and set Max Bellows Contraction (unit is mm).







Precautions for Correct Use

The vacuum hand assumes that the pad is pressed against the workpiece within the range of Max Bellows Contraction and grasps it. If there is no bellows element, set the difference in length between the non-adsorbed state and the adsorbed state of the adsorbed rubber (deformation of the tip) as a bellows. When the bellows are not set, or the Max Bellows Contraction is 0 mm, it is determined that the work piece and the hand interfere with the grasp point registration.

5 ■Pipe and Flange connection jig
Click Add Cylinder and then
select Base from the pulldown list.



Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (pipe).



Click **Add Cylinder** and then select **Base** from the pulldown list.

HandMaker

Name

New Parts

New Parts

New Parts


Group

Bellows

Pad

Base

Open "Individual parts" tab. Set Position, Orientation and dimension of each element (flange connection jig).



Add Cylinde

Delete

Сору


6 ■On-Hand Camera
Assume the size of the On-Hand
Camera to be 110x70x90mm.
Click Add Rectangle button and
select Base from the pulldown list.




Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (On-Hand camera).

To tilt the camera, set **Tilt Direction** and **Tilt Angle [deg]**.

This hand model does not have rotational symmetry because of the camera, so open "Whole hands" tab and remove the check from the **Symmetry** check box.






Open "Grasp DB" to make a Grasp DB and register grasp points.

Select a target object from CAD Data list and select a hand from Hand Data list.

Click the **New** button to open the GraspTeachGUI tool.








11 With the left button of the mouse pressed, drag the target object CAD on the screen to rotate and make its grasp side visible on the screen.


Move mouse on the grasp point and right click. The hand will be displayed on the grasp point like the figure shown on the right.

When **Push-in Amount of Grip Teach [mm]** is set, the suction pad will be automatically pushed into workpieces.









The Grasp point location and posture is adjusted by using "Hand transformation" buttons. The function of the button are as follows.

Adjust the position of the hand by clicking the + or - button for each axis.

The amount of movement can be selected from the pull-down list.

The bellows shrink (contraction) condition can be seen by placing check on the "Shrink bellows" check box.

Consider shrink and no shrink condition of the bellows and adjust proper grasp point.


The Grasp point placed by right mouse button click is just surface of the target object. If it is not the right place for vacuum grasping, move the hand lower by clicking **Trans Z +/-** button.


Some type of grasp points can be generated automatically.


Multiple point around Z axis is generated by Circle button.


Number of multiple point and angle is adjustable by using [+]/[-] button shown in right figure.


Move mouse to other point and right click adds next grasp point.











In some condition, the robot may not reach the set grasp point. Add grasp points considering the workpiece's orientation and the robot's rotational range limit.

[<-Prev] button displays previous grasp point, [Next->] button displays next grasp point.

Delete button deletes current grasp point.

After setting all grasp points, click [Save] button at right lower side of the window.

When the dialog "Grasp DB has been saved successfully" pops up, click the **OK** button.


If a warning dialog appears, please review grasp points that do not touch, or collide with the workpiece. For detail, refer to *Key Points for Adjustment(3D Data Manager) or 3D Data manager* in the *Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision* (Cat. No. Z445)

Then click the [Exit] button.


Click the Rename button to change the Grasp DB name from the system default name.

Input any name in the dialog box and then click **OK** to apply the change.

The Grasp point registration process is completed by the above operations.







Click the OK button to complete the setting and close Hand and Grasp point registration, and 3D Data Manager unit.


Click the Scene switch button in the main window. And switch scene to sample scene (No.0 scene).



Precautions for Correct Use

- Set the grasp point based on the actual posture of workpieces, the movement range of the robot, and the shape and placement of the hand.
- If you need to set more than one grasp point and consider how to place the hand for each grasp point, design the robot program depending on the grasp point.
- ■Supplementary Information on Grasp Point.

The figure below illustrates why multiple grasp point registrations are necessary.



Grasp points No.1 to No. 4 are defined as follows.

No. 1	Grasp point on the front No. 2		Grasp point with the hand rotated	
	side of the workpiece		180 deg from grasp point No. 1	
No. 3	Grasp point on the back No		Grasp point with the hand rotated	
	side of grasp point No. 1		180 deg from grasp point No. 3	

1) Consideration for the rotation angle range of the robot

If the robot cannot reach the registered grasp point due to the limited rotation angle of the robot or the shape of the container or hand, add grasp points to locations where the robot can reach. As shown in the above figure where the rotation angle of the robot hand is limited to $\pm\theta$ deg, the robot can grasp workpiece A but cannot grasp workpiece B at grasp point No.1 due to the limited rotation angle. Therefore, grasp point No.2 is added. In the Grasp Planning procedure in the next section, it will compare grasp points No. 1 and No. 2 for workpiece B and select grasp point No. 2 where the robot does not reach the rotation limit.


2) Consideration for symmetry of the workpiece


When the workpiece has a front to back symmetry, it may be recognized as the front or back side even in the same posture in the result of 3D Search. Therefore, registering only grasp points No. 1 and No. 2 on the front side is not sufficient, if it is recognized as the back side. Therefore, grasp points No. 3 and No. 4 are added. However, when the *Having front and back symmetry about current view* check box is selected in 3D Search model registration, grasp points No. 3 and No. 4 need not be registered.

In addition, when the workpiece has a horizontal (or vertical) symmetry, even in the same view, it may be recognized as being rotated 0 or 180 deg to the Z axis of the camera coordinate system in the result of 3D Search. Therefore, grasp points are registered in 180-deg symmetrical locations as in the relationship between grasp points No. 1 and No. 2.

8.8.7. Grasp Planning

Follow the setting procedure below for priority ordering of the target object and collision checking. The Grasp planning unit refers HandEye Calibration unit, Container Detection unit and 3D Search unit. Confirm those units are correctly working.





Priority order is divided in to 3 levels (High/Low/Reject) by 2 parameters (Preferred /Reject) as shown in the figure on the right The final priority will be determined based on the overall evaluation of each evaluation value. Candidates with more items that are at "Preferred level" or higher will be given higher priority.

Items with no condition selected will be set to "Rejection level" and excluded.


■3D Search result

Threshold of 3D Search (section 8.8.5) matching level is set to Surface correlation and Contour correlation.

All candidates detected in 3D Search are the target of evaluation. Candidates that are rejected due to the judgment conditions will also be included.

■Tilt and Rotation angle
The priority will be set based on
the tilt and rotation of the hand tip
when the workpiece is grasped.

Tilt of hand and Rotation of hand provide the allowable limits for the amount of tilt and rotation (rotation angle) of the hand at the time of grasping workpieces. The condition is whether candidates fall in the range above or below the set value. Set a safe range for each item, considering the collision with the environment and the cable length.



Surface correlation :	97.3129 (A)
Prefferred level :	60 < >
Rejection level :	30 < >
Contour correlation :	81.5972 (A)
Prefferred level :	60 < >
Rejection level :	30 < >

Tilt of hand [deg] :	8.8037 (A)
Prefferred level :	40.0000 < >
Rejection level :	90.0000 < >
Rotation of hand [deg] :	29.9322 (A)
Prefferred level :	90.0000 < >
Rejection level :	120.0000 < >

For **Tilt of hand**, the angle reference varies depending on whether or not **Target object** is set to *None* in the Collision detection tab.

When **Target object** is *Floor* + *container*, the normal to the floor is the reference.

When **Target object** is *None*, the optical axis of the camera is the reference.

To limit the tilt angle, set **Rejection level** to the limit angle.


For **Rotation of hand**, set the reference by clicking the **Advanced** button. The angle formed between the two reference vectors selected in the Advanced window represents the amount of rotation.


Select a robot base coordinate axis in measurement pose and select a flange coordinate axis for rotation object.

The angle of "Rotation of hand" is angle between selected vectors. Select two vectors that are same direction when the robot is in measurement position.

Setting examples are given in Supplementary Information on the Amount of Hand Rotation at the end of this section.

If there is no applicable direction, select *Custom* and set an appropriate angle.





■Depth of the work pos.

The priority will be set based on the depth of the target. Use these settings to give priority to workpieces placed in shallower (upper) depth.

In **Depth of work pos.**, set the candidate selection range in the direction of depth with reference to the workpiece detected at the highest position.

The direction in which the depth is measured differs depending on whether or not **Target object** is set to *None* in the Collision detection tab.

If Target object is set to Floor or Container, the depth will be judged by the distance along the normal to the floor.


In cases other than the above, the depth will be judged by the distance along the optical axis of the camera.


■Same priority

Able to set priority for same score candidates.

Click [Advanced] button to set "Treatment about a same priority one" for same score candidates.

Click the [Return] button to close advanced setting.







Precautions for Correct Use


The candidates detected as a result of 3D Search will be input to the Grasp Planning processing item regardless of the judgment result OK/NG. To use only the 3D Search judgment result OK, set the threshold of the 3D Search judgment condition in **Rejection level** for **Surface correlation** or **Contour correlation**.


- Open "Collision detection" to set collision detection condition.
 - ■Collision with hand Set collision margin of hand in "Collision with hand". The hand model size is enlarged by the "Margin mm" at collision check calculation.
 - ■Collision with surrounding environment.


Select the target objects that collide with the hand. Objects are Floor, Container, Container + Floor or None. Specifying the "Container Detection" unit that set in the section 8.8.4 is necessary for Collision detection.

Set the margin by which to extend the container and/or floor during collision detection.

■Collision with point cloud. Set "Outlier height" for ignoring outlier point cloud which must be noise. The height is measured from the floor plane.








Container and gripper


Gripper and floor container





Set "Tolerance" for ignoring point cloud collision with hand caused by measurement noise.

Click **OK** button to close the setting window.




Gripper and point cloud




Precautions for Correct Use

- Setting a margin in Collision with hand reduces the risk of contact with the container or other workpieces. However, for two-finger hands, the setting reduces the actual opening width. Consider the size of the workpieces and the opening width when you set the margin.
- Setting a margin in Collision with the surrounding environment reduces the risk of a collision between the hand and the container. However, setting it too large may result in detecting a collision at workpiece grasp points near the wall of the container.
- 9 Click the **Measure** button to execute measurement.



10 Open Grasp Planning "Collision detection" tab.

If the measurement is successful, green outline will be overlaid on the 2D workpiece image.





Click **Draw with 3D** button to run the 3D Visualizer.

Grasp candidates and pose and posture is displayed on screen.

Following mouse operation is available to check grasp condition.


Left down + drag : Rotation
Shift+Left down+drag:Translation
Rotate Wheel : Scaling
Visible/Invisible of each element
can switch by radio button.


Click [End] to close 3D Visualiz.


In **Display settings**, check **Draw rejected work** and **Draw rejected reason**. A purple outline will be overlaid on the rejected workpiece image.


In **Detected work index focused**, use the > button to go through the work numbers to display the rejection reason for the rejected workpiece in red text.

The figure on the right is an example of how the rejection reason is displayed on the rejected workpiece image.









If the number of grasp candidates is 0 even though a workpiece is detected in 3D Search, check the following to narrow down the causes.

- 1) Current position of the robot, hand-eye calibration unit
 Confirm that the **Hand-Eye data unit settings** in the Coordinate settings tab are
 correct. In addition, confirm that the coordinate values of the flange coordinate system
 viewed from the robot base coordinate system are correct and correctly reflect the
 posture of the robot when the image is captured.
- 2) Collision with the surrounding environment

In *Collision with the surrounding environment* in the Collision detection tab, set *Target object* to *None* and measure again. A collision with the container and/or floor may occur due to the condition setting.


3) Tilt and Rotation

Check if the "Ref. vector for hand" vector is set correctly. Refer to the setting examples at the end of this section. Also, in *Tilt of hand [deg]* and *Rotation of hand [deg]* in the Order of grasping tab, increase the angle values and measure again. The condition settings may be too strict, or the number of registered grasp points that meet the conditions may be insufficient.

- 4) Collision with point cloud
- In Collision with point cloud in the Collision detection tab, increase the *Tolerance* [point] value and measure again. The tolerance may be too strict.
- 5) Margin settings

In the Collision detection tab, decrease the set *margin* values for *Collision with hand* and *Collision with the surrounding environment*, and measure again. The set margin values may be too large.

Open the Judge cond. tab. For each judgment condition, set the range in which the unit is to be judged as OK.



This completes the Grasp
Planning setting procedure.
At the time of measurement, the grasp point selected based on the condition settings configured in the **Order of grasping** tab in this section will be output in the robot coordinate system.

12 Click **OK** to complete Grasp Planning and close the setting screen.

△WARNING

The movement of each axis and each arm of the robot with respect to the grasp point output in the Grasp Planning processing item depends on the operation algorithm of the robot. Thoroughly test that the movement of the robot arm does not cause the 3D vision sensor or hand to collide with the robot or apply a greater load than the specified value to the cable.



■Supplementary Information on the Amount of Hand Rotation

Examples of setting the amount of hand rotation are shown below. The subscript b, f, or c next to each coordinate axis name in the figure represents the base coordinate system, flange coordinate system, or camera coordinate system, respectively.


A 3D vision camera (the camera in the figure) is fixed to the flange of the robot. In this setting, two examples are shown, where the Y-axis minus direction of the flange coordinate system and the Y-axis minus direction of the camera coordinate system are used under one installation condition.

	Setting example			Layout (top view)
1		Ref. vector for hand rot(robot base coord)	Ref. vector for hand rot(frange coord)	X_c X_f Container Y_c
	(1)	X-axis plus direction	Y-axis minus direction (Camera coordinate system)	Camera
	(2)	X-axis plus direction	Y-axis minus direction	Y_b
	Since the Y axis of camera coordinate system and the Y axis of the flange coordinate system have the same direction, setting examples (1) and (2) produce the same result.			
2	(1)	Ref. vector for hand rot(robot base coord) X-axis plus direction	Ref. vector for hand rot(frange coord) Y-axis minus direction (Camera coordinate system)	Container X_c X_f Y_c Y_f X_b
	(2)	X-axis plus direction	X-axis minus direction	Y_{b}
	Since the Y axis of camera coordinate		mera coordinate	
	system and the X axis of the flange			
	coordinate system have the same			
	direction, setting examples (1) and (2)			
	produce the same result.			

3	Ref. vector for hand rot(robot base coord) (1) Y-axis plus Y-axis minus direction (Camera coordinate system) (2) Y-axis plus Y-axis minus direction direction direction						
			(Camera coordinate	X_b Y_f Y_b			
			Y-axis minus direction	Container			
	Sinc	e the Y axis of car	nera coordinate	X _C			
	syste	em and the Y axis	of the flange				
	coor	dinate system hav	e the same				
	direc	ction, setting exam	ples (1) and (2)				
	prod	uce the same res	ult.				
4		Ref. vector for	Ref. vector for hand				
	hand rot(robot rot(frange coord) base coord)		rot(frange coord)				
	(1)	Y-axis plus	Y-axis minus direction	X_b			
		direction	(Camera coordinate				
			system)	$X_f \left[\begin{array}{c} Y_b \end{array} \right]$			
	(2) Y-axis plus X-axis minus direction		X-axis minus direction	Container Y_f			
	direction			Y _c Camera			
	Since the Y axis of camera coordinate			X_c			
	system and the X axis of the flange						
	coor	dinate system hav	e the same				
	direc	ction, setting exam	ples (1) and (2)				
	prod	uce the same res	ult.				

8.8.8. Result Output

Result of Grasp Planning is sent to the robot through Ethernet serial communication. If you load a sensor controller project corresponding to the robot type, there is no need to enter or change the settings because the system variables (SY.XXX) are already set.




If you add, delete, or change the order of items in the result output, the robot will perform an unexpected operation. Do not change the settings.



8.8.9. Saving the Settings

You have completed the settings on the Vision Sensor side in the previous section. In this section, enable the output of the measurement results to external devices and save the settings.



For how to operate the robot to pick a workpiece based on the settings in this manual, refer to section 6 of the *Vision System FH/FHV series Robot Connection Guide* corresponding to the robot listed in *Related Manuals* in this manual.

8.8.10. Troubleshooting

For troubleshooting for each processing item in the picking application, refer to *Key Points* for Test Measurement and Adjustment for each processing item in the Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445).

9. Appendix


9.1. Making Hand (Tow finger Gripper) and Grasp Point Registration

Register the shape of the hand used to grasp workpieces. You can also register a camera as part of the hand to include in collision detection with the container.

You can create one-point vacuum and two-finger hands.


For details on each parameter of the processing item, refer to 3D Data Manager in the following manual. Vision System FH series Processing Item Function Reference Manual for 3D Robot Vision (Cat. No. Z445)

This section explains how to register the tow finger hand by using example shown in below figure. The unit is mm.



■Hand coordinate


Hand data uses the robot flange coordinate system. Check the orientation of the robot flange coordinate system when you install the hand.



■Components of the hand

The two-finger hand consists of the following elements.


Element	Description		
Left finger	Left finger part. This is movable.		
Left tip finger	The left finger tip part that grasps workpieces. This is movable.		
	You must register only one part.		
Right finger	Right finger part. This is movable.		
Right tip finger	The right finger tip part that grasps workpieces. This is movable.		
	You must register only one part.		
Base	Structural elements other than the above. Elements such as flange		
	mounting bracket, hand actuator, camera, and jig that are linked to the		
	6th axis of the robot and required for collision detection are registered as		
	Base.		



■Location and dimensions of components


Position and posture of elements are described in the flange coordinate. The position of the element is center of roof plane or cross section of diagonal line. Height/ Width Z is minus Z direction in flange coordinate system.

The root of the hand is located at the origin of the flange coordinate system. Create the tip of the hand in the Z-axis plus direction of the flange coordinate system.



■Accuracy of the hand

Accurately set the positions and dimensions of the left and right tip fingers that make contact with workpieces (shown in a red outline in the figure below). In particular, set the dimensions in the Z-axis direction of the flange coordinate system correctly. For other elements that may collide with the container (shown in a yellow outline in the figure below), you can use approximate shapes such as circumscribed cubes and cylinders without problems.







Precautions for Correct Use


- Output of the Vision Sensor is calculated based on the hand shape specified here. Position and size of the element which contact to the target object must be set precisely.
- Register the elements attached to the hand (camera, connectors, jigs attached to the hand, etc.) that require collision judgement with the container together with the hand.

Follow the steps below to register the hand data, and then register the grasp point.







Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (Rectangle)



7 ■Right tip finger
Click Add Rectangle and then
select Right tip finger from the
pulldown list.

Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (Rectangle)





△ Caution

 Accurately set the positions, postures and dimensions of the left and right tip fingers. If they differ from the actual dimensions or positions, the hand may collide with workpieces or the container.




8 ■Left finger

Copy the right finger part to make the left finger part.

In the right hand part, select the element that you set to *Right finger* and click the **Copy** button. Since the hand is symmetrical to the XZ plane of the flange coordinate system, click the **Reverse (X-Z Plane)** button to reverse the position.

Change the group of the reversed element to *Left finger*.

In the Individual Parts tab, check that the position/orientation and size settings are correct.



9 ■Left finger tip


Copy the right finger tip part to make the left finger tip.


In the right finger tip part, select the element that you set to *Right tip finger* and click the **Copy** button.

Since the hand is symmetrical to the XZ plane of the flange coordinate system, click the **Reverse (X-Z Plane)** button to reverse the position.

Change the group of the reversed element to *Left tip finger*. If necessary, rename it.

In the Individual Parts tab, check that the position/orientation and size settings are correct.








10 ■On-Hand Camera


Assume the size of the On-Hand Camera to be 110x70x90mm. Click [Add Rectangle] button and select "Base" from the pulldown list.

Open the "Individual parts" tab. Set Position, Orientation and dimension of each element (On-Hand camera).












Use the **Hand transformation** buttons to finely adjust the grasp point. Use each button as follows. Click the **+ or -** button for each axis to adjust the position of the hand.



Use the guide on display to adjust the position so that the left and right fingers are equidistant from the workpiece.




If the position of the hand causes a collision with the workpiece as shown in the figure on the right, the fingers will be shown in yellow. In this case, adjust the position to prevent collisions.



You can add a grasp point by right-clicking another place on the workpiece.

16 If the object is a cylinder, etc., you can use the **OffsetZ** buttons to push in and move the grasp point to a stable place.




17 Some type of grasp points can be generated automatically.


Multiple point around axis are generated by Fan or Circle button.

Number of multiple point and angle is adjustable by using [+]/[-] button shown in right figure.

Start angle Stop angle

Click the **Single** button to cancel the **Fan** or **Cylinder** setting mode.





21	Click the Scene switch button in	
	the main window. And switch	
	scene to sample scene (No.0	
	scene).	




Precautions for Correct Use

- Set the grasp point based on the actual posture of workpieces, the movement range of the robot, and the shape and placement of the hand.
- If you need to set more than one grasp point and consider how to place the hand for each grasp point, design the robot program depending on the grasp point.

9.2. Robot Error

When an error occurs during communication with a robot, click the **Robot Error** button to display the following screen.



The following table shows the error messages and corrective actions that may be displayed.

Error	Possible cause / Corrective action					
Failed to send the command	Robots and/or Vision Sensor may have incorrect					
	communication settings. Adjust the settings of the IP address					
	and port number of the robot controller and Vision Sensor.					
	The setup program may not have been started on the robot					
	side. Operate with the setup program activated on the robot.					
The Connection had timed out	The robots did not respond to Vision Sensor commands					
	within a certain time period. Due to the slow robot operation					
	speed, the robot may not complete its movement within the					
	set communication timeout period. Increase the					
	communication timeout time. Or increase the operation speed					
	of the robot.					
Measure failed	Measurement trigger may have been sent when the Processing Item or System Setting window is open.					
	Do not send measurement trigger when the process unit or					
	the system setting window is open.					
Failed to move robot	• The destination robot position sent from the Vision Sensor					
	may be out of movement range. Adjust the parameters of the					
	robot operation range so that the robot position of the					
	destination is within the movement range. Alternatively, adjust					
	the settings of the Hand-eye Calibration unit and Grasp					
	Planning unit.					
Measurement result is NG	• The measurement result is NG. Adjust the setting of the					
	processing unit with the result of NG.					

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968
Tel: (65) 6835-3011 Fax: (65) 6835-3011

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388 **Authorized Distributor:**

©OMRON Corporation 2021-2024 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. Z446-E1-06 0624